

The Samsung logo is located in the top left corner, consisting of the word "SAMSUNG" in a bold, sans-serif font, enclosed within a white oval shape.

User's Guide

# ***Digital Laser MFP***

**SCX-4216F**

**SCX-4116**

**SCX-4016**

**For UK customers:**

**To reorder your consumables**

**Call 0800 3164060**

**For Technical Assistance**

**Call 0870 2420303**

# About the User's Guides

## Your machine comes with the three user's guides:

**This Laser MFP User's Guide** provides information you need for setting up your machine and installing the supplied software. It also provides all of the detailed instructions for using your machine as a printer, a scanner and a copier and information for maintaining and troubleshooting the machine.

**The Laser Facsimile User's Guide** (only for SCX-4216F) provides information for using your machine as a fax machine. You can find how to send and receive a fax, and how to set fax-related options.

**The SmarThru 3 User's Guide** provides the basic description about using the multi-function application. Samsung SmarThru allows you to scan and edit images, and to scan for copying, faxing and sending an e-mail on your computer. You can also find a brief description on the automatic text recognition program, AnyPage.

This manual is provided for information purposes only. All information included herein is subject to change without notice. Samsung Electronics is not responsible for any changes, direct or indirect, arising from or related to use of this manual.

© 2002 Samsung Electronics Co., Ltd. All rights reserved.

- SCX-4016, SCX-4116, SCX-4216F and Samsung logo are trademarks of Samsung Electronics Co., Ltd.
- SmarThru, MailBox, Image Manager, Scan Manager, Copy Manager, Image Viewer, AnyPage are trademarks of Samsung Electronics.
- Centronics is a trademark of Centronics Data Computer Corporation.
- IBM and IBM PC are trademarks of International Business Machines Corporation.
- Apple, AppleTalk, TrueType, LaserWriter and Macintosh are trademarks of Apple Computer, Inc.
- Microsoft, Windows, Windows 9x, Window Me, Windows 2000, Windows NT 4.0 and Windows XP are registered trademarks of Microsoft Corporation.
- All other brand or product names are trademarks of their respective companies or organizations.

# CONTENTS

## *Chapter 1:* **GETTING STARTED**

|  |      |
|--|------|
| Unpacking .....                            | 1.2  |
| Selecting a Location .....                 | 1.4  |
| Understanding the Component Location ..... | 1.5  |
| Front View .....                           | 1.5  |
| Rear View .....                            | 1.6  |
| Control Panel Functions .....              | 1.7  |
| Installing the Toner Cartridge .....       | 1.10 |
| Loading Paper .....                        | 1.12 |
| Making Connections .....                   | 1.15 |
| Turning the Machine On .....               | 1.17 |
| Changing the Display Language .....        | 1.17 |
| Setting the Paper Type and Size .....      | 1.18 |
| Using the Save Modes .....                 | 1.19 |
| Toner Save Mode .....                      | 1.19 |
| Power Save Mode .....                      | 1.19 |
| CCD Power Save Mode .....                  | 1.20 |

## *Chapter 2:* **INSTALLING SOFTWARE**

|  |      |
|--|------|
| About Samsung Software .....                     | 2.2  |
| System Requirements .....                        | 2.3  |
| Installing Samsung Software in Windows .....     | 2.4  |
| Installing the USB Driver in Windows 98/Me ..... | 2.8  |
| Uninstalling Samsung Software .....              | 2.9  |
| Uninstalling the MFP Driver .....                | 2.9  |
| Uninstalling Samsung SmarThru .....              | 2.10 |
| Using the CD-ROM .....                           | 2.12 |

## **Chapter 3: PAPER HANDLING**

|   |      |
|---|------|
| Selecting Print Materials .....                       | 3.2  |
| Size, Input Sources and Capacities .....              | 3.2  |
| Guidelines for Paper and Special Materials .....      | 3.3  |
| Selecting an Output Location .....                    | 3.4  |
| Printing to the Front Output Tray (Face down) ....    | 3.5  |
| Printing to the Rear Output Slot (Face up) .....      | 3.5  |
| Loading Paper in the Paper Tray .....                 | 3.6  |
| Using the Bypass Tray .....                           | 3.8  |
| Setting the Paper Type and Size for the Bypass Tray . | 3.10 |

## **Chapter 4: COPYING**

|  |      |
|--|------|
| Loading Paper for Copying .....  | 4.2  |
| Making Copies on the Document Glass .....                                      | 4.2  |
| Making Copies from the Automatic Document Feeder (For<br>SCX-4116/4216F) ..... | 4.4  |
| Setting Copy Options .....   | 4.5  |
| Contrast .....   | 4.6  |
| Image .....  | 4.6  |
| Reduced/Enlarged Copy .....  | 4.7  |
| Number of Copies .....   | 4.7  |
| Using Special Copy Features .....  | 4.8  |
| Auto Fit Copying .....   | 4.8  |
| Clone Copying .....  | 4.9  |
| Collation Copying .....  | 4.10 |
| 2-side Copying .....   | 4.10 |
| 2-up or 4-up Copying .....   | 4.11 |
| Poster Copying .....   | 4.12 |
| Changing the Default Settings .....  | 4.13 |
| Setting the Time Out Option .....  | 4.14 |

## **Chapter 5: PRINTING**

|  |      |
|--|------|
| Printing a Document .....  | 5.2  |
| Canceling a Print Job .....  | 5.5  |
| Using a Favorite Setting .....   | 5.6  |
| Using Help .....   | 5.6  |
| Setting Paper Properties .....   | 5.7  |
| Printing Multiple Pages on One Sheet of Paper (N-Up Print-<br>ing) ..... | 5.8  |
| Printing a Reduced or Enlarged Document .....                            | 5.10 |



|  |      |
|--|------|
| Fitting Your Document to a Selected Paper Size ..... | 5.11 |
| Printing Posters .....                               | 5.12 |
| Using Watermarks .....                               | 5.13 |
| Using an Existing Watermark .....                    | 5.13 |
| Creating a Watermark .....                           | 5.14 |
| Editing a Watermark .....                            | 5.15 |
| Deleting a Watermark .....                           | 5.15 |
| Using Overlays .....                                 | 5.16 |
| What is an Overlay? .....                            | 5.16 |
| Creating a New Page Overlay .....                    | 5.16 |
| Using a Page Overlay .....                           | 5.18 |
| Deleting a Page Overlay .....                        | 5.19 |
| Setting Graphic Properties .....                     | 5.20 |
| Setting Up the Locally Shared Printer .....          | 5.22 |
| In Windows 9x/Me .....                               | 5.22 |
| In Windows NT 4.0/2000/XP .....                      | 5.23 |

## *Chapter 6:* **SCANNING**

|  |     |
|--|-----|
| Scanning Basics .....                              | 6.2 |
| Scanning Using the Samsung SmarThru .....          | 6.2 |
| Scanning Process with TWAIN-enabled Software ..... | 6.5 |

## *Chapter 7:* **MAINTENANCE**

|  |      |
|--|------|
| Clearing the Memory .....                                | 7.2  |
| Cleaning Your Machine .....                              | 7.3  |
| Cleaning the Outside .....                               | 7.3  |
| Cleaning the Inside .....                                | 7.3  |
| Cleaning the Scan Unit .....                             | 7.4  |
| Maintaining the Toner Cartridge .....                    | 7.5  |
| Redistributing Toner .....                               | 7.6  |
| Replacing the Toner Cartridge .....                      | 7.7  |
| Setting the Notify Toner Option<br>(For SCX-4216F) ..... | 7.9  |
| Cleaning the Drum .....                                  | 7.9  |
| Consumables and Replacement Parts .....                  | 7.10 |

## *Chapter 8:* **TROUBLESHOOTING**

|   |      |
|---|------|
| Clearing Document Jams (For SCX-4116/4216F) ..... | 8.2  |
| Input Misfeed .....                               | 8.2  |
| Exit Misfeed .....                                | 8.3  |
| Roller Misfeed .....                              | 8.3  |
| Clearing Paper Jams .....                         | 8.4  |
| In the Paper Feed Area .....                      | 8.4  |
| In the Paper Exit Area .....                      | 8.5  |
| In the Fuser Area or Around the Toner Cartridge . | 8.7  |
| In the Bypass Tray .....                          | 8.8  |
| Tips for Avoiding Paper Jams .....                | 8.9  |
| Clearing LCD Error Messages .....                 | 8.10 |
| Solving Problems .....                            | 8.13 |
| Paper Feeding Problems .....                      | 8.13 |
| Printing Problems .....                           | 8.14 |
| Printing Quality Problems .....                   | 8.17 |
| Fax Problems (For SCX-4216F) .....                | 8.21 |
| Copying Problems .....                            | 8.23 |
| Scanning Problems .....                           | 8.24 |
| Common Macintosh Problems .....                   | 8.25 |

## **Chapter A: PRINTING FROM A MACINTOSH**

|   |     |
|---|-----|
| Installing Software for Macintosh ..... | A.2 |
| Installing Software .....               | A.2 |
| Choosing Your Printer .....             | A.4 |
| Printing a Document .....               | A.4 |
| Using Advanced Printing Features .....  | A.6 |

## **Chapter B: SPECIFICATIONS**

|  |     |
|--|-----|
| General Specifications .....                   | B.2 |
| Scanner and Copier Specifications .....        | B.3 |
| Printer Specifications .....                   | B.4 |
| Facsimile Specifications (For SCX-4216F) ..... | B.5 |
| Paper Specifications .....                     | B.6 |
| Overview .....                                 | B.6 |
| Supported Sizes of Paper .....                 | B.6 |
| Guidelines for Using Paper .....               | B.7 |
| Paper Specifications .....                     | B.8 |
| Paper Output Capacity .....                    | B.9 |
| Printer and Paper Storage Environment .....    | B.9 |

## Important Precautions and Safety Information

When using this machine, these basic safety precautions should always be followed to reduce risk of fire, electric shock, and injury to people:

1. Read and understand all instructions.
2. Use common sense whenever operating electrical appliances.
3. Follow all warnings and instructions marked on the machine and in the literature accompanying the machine.
4. If an operating instruction appears to conflict with safety information, heed the safety information. You may have misunderstood the operating instruction. If you cannot resolve the conflict, contact your sales or service representative for assistance.
5. Unplug the machine from the AC wall socket and/or telephone jack before cleaning. Do not use liquid or aerosol cleaners. Use only a damp cloth for cleaning.
6. Do not place the machine on an unstable cart, stand or table. It may fall, causing serious damage.
7. Your machine should never be placed on, near or over a radiator, heater, air conditioner or ventilation duct.
8. Do not allow anything to rest on the power. Do not locate your machine where the cords will be abused by persons walking on them.
9. Do not overload wall outlets and extension cords. This can diminish performance, and may result in the risk of fire or electric shock.
10. Do not allow pets to chew on the AC power, telephone or PC interface cords.
11. Never push objects of any kind into the machine through case or cabinet openings. They may touch dangerous voltage points, creating a risk of fire or shock. Never spill liquid of any kind onto or into the machine.
12. You machine may have a heavy cover for optimal pressure on the document for the best scanning and/or faxing (usually the flatbed-type machine). In this case, replace the cover after placing document on the scan glass, by holding and moving it down slowly until it seats on its location.
13. To reduce the risk of electric shock, do not disassemble the machine. Take it to a qualified service technician when repair work is required. Opening or removing covers may expose you to dangerous voltages or other risks. Incorrect reassembly could cause electric shock when the unit is subsequently used.
14. Unplug the machine from the telephone jack, PC and AC wall outlet, and refer servicing to qualified service personnel under the following conditions:
  - When any part of the power cord, plug, or connecting cable is damaged or frayed.
  - If liquid has been spilled into the machine.

- If the machine has been exposed to rain or water.
  - If the machine does not operate properly after instructions have been followed.
  - If the machine has been dropped, or the cabinet appears damaged.
  - If the machine exhibits a sudden and distinct change in performance.
15. Adjust only those controls covered by the operating instructions. Improper adjustment of other controls may result in damage, and may require extensive work by a qualified service technician to restore the machine to normal operation.
16. Avoid using this machine during a lightning storm. There may be a remote risk of electric shock from lightning. If possible, unplug the AC power and telephone cord for the duration of the lightning storm.
17. SAVE THESE INSTRUCTIONS.

## Laser Safety Statement

The printer is certified in the U.S. to conform to the requirements of DHHS 21 CFR, chapter 1 Subchapter J for Class I(1) laser products, and elsewhere is certified as a Class I laser product conforming to the requirements of IEC 825.

Class I laser products are not considered to be hazardous. The laser system and printer are designed so there is never any human access to laser radiation above a Class I level during normal operation, user maintenance, or prescribed service condition.

### WARNING

Never operate or service the printer with the protective cover removed from Laser/Scanner assembly. The reflected beam, although invisible, can damage your eyes.

|   |   |
|---|---|
|    | CAUTION - INVISIBLE LASER RADIATION<br>WHEN THIS COVER OPEN.<br>DO NOT OPEN THIS COVER.           |
|   | VORSICHT - UNSICHTBARE LASERSTRAHLUNG,<br>WENN ABDECKUNG GEÖFFNET.<br>NICHT DEM STRAHL AUSSETZEN. |
| ATTENTION - RAYONNEMENT LASER INVISIBLE EN CAS<br>D'OUVERTURE. EXPOSITION DANGEREUSE<br>AU FAISCEAU.                            |   |
| ATTENZIONE - RADIAZIONE LASER INVISIBILE IN CASO DI<br>APERTURA. EVITARE L'ESPOSIZIONE AL FASCIO.                               |   |
| PRECAUCIÓN - RADIACIÓN LASER INVISIBLE CUANDO SE ABRE.<br>EVITAR EXPONERSE AL RAYO.   |   |
| PERIGO - RADIAÇÃO LASER INVISÍVEL AO ABRIR. EVITE<br>EXPOSIÇÃO DIRECTA AO FEIXE.  |   |
| GEVAAR - ONZICHTBARE LASERSTRALEN BIJ GEOPENDE<br>KLEP. DEZE KLEP NIET OPENEN.  |   |
| ADVARSEL - USYNLIG LASERSTRÅLNING VED ÅBNING, NÅR<br>SIKKERHEDSBRYDERE ER UDE AF FUNKTION.<br>UNDGÅ UDSAETTELSE FOR STRÅLNING.  |   |
| ADVARSEL - USYNLIG LASERSTRÅLNING NÅR DEKSEL<br>ÅPNES. STIRR IKKE INN I STRÅLEN. UNNGÅ<br>EKSPONERING FOR STRÅLEN.              |   |
| VARNING - OSYNLIG LASERSTRÅLNING NÅR DENNA DEL<br>ÄR ÖPPEN OCH SPÄRREN ÄR URKOPPLAD.<br>BETRakta EJ STRÅLEN. STRÅLEN ÄR FARLIG. |   |
| VARO! - AVATTAESSA JA SUOJALUKITUS OHITETTAESSA<br>OLET ALTIINA NÄKYMÄTÖMÄLLE LASER-<br>SÄTEILYLLE ÄLÄ KATSO SÄTEESEEN.         |   |
| <b>注意</b> - 严禁揭开此盖, 以免激光泄露灼伤  |   |
| 주의 - 이 덮개를 열면 레이저광에 노출될 수 있으므로<br>주의하십시오.   |   |

## Ozone Safety



During normal operation, this machine produces ozone. The ozone produced does not present a hazard to the operator. However, it is advisable that the machine be operated in a well ventilated area.

If you need additional information about ozone, please request your nearest Samsung dealer.

## Power Saver



This machine contains advanced energy conservation technology that reduces power consumption when it is not in active use.

When the machine does not receive data for an extended period of time, power consumption is automatically lowered.

The energy star emblem does not represent EPA endorsement of any machine or service.

## Radio Frequency Emissions

### FCC Information to the User

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or experienced radio TV technician for help.

---

**CAUTION:** Change or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.

---

## Canadian Radio Interference Regulations

This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus as set out in the interference-causing equipment standard entitled "Digital Apparatus", ICES-003 of the Industry and Science Canada.

Cet appareil numérique respecte les limites de bruits radioélectriques applicables aux appareils numériques de Classe B prescrites dans la norme sur le matériel brouilleur: "Appareils Numériques", ICES-003 édictée par l'Industrie et Sciences Canada.

## Fax Branding

The Telephone Consumer Protection Act of 1991 makes it unlawful for any person to use a computer or other electronic device to send any message via a telephone facsimile machine unless such message clearly contains in a margin at the top or bottom of each transmitted page or on the first page of the transmission the following information:

- (1) the date and time of transmission
- (2) identification of either business, business entity or individual sending the message; and
- (3) telephone number of either the sending machine, business, business entity or individual.

Refer to the Facsimile User's Guide for instructions on how to enter this information into your machine's memory.

The Telephone Company may make changes in its communications facilities, equipment operations, or procedures where such action is reasonably required in the operation of its business and is not inconsistent with the rules and regulations in FCC Part 68. If such changes can be reasonably expected to render any customer terminal equipment incompatible with telephone company communications facilities, or require modification or alteration of such terminal equipment, or otherwise materially affect its use or performance, the customer shall be given adequate notice in writing, to allow the customer an opportunity to maintain uninterrupted service.

## Ringer Equivalence Number

The Ringer Equivalence Number and FCC Registration Number for this machine may be found on the label located on the bottom or rear of the machine. In some instances you may need to provide these numbers to the telephone company.

The Ringer Equivalence Number (REN) is a measure of the electrical load placed on the telephone line, and is useful for determining whether you have "overloaded" the line. Installing several types of equipment on the same telephone line may result in problems making and receiving telephone calls, especially ringing when your line is called. The sum of all Ringer Equivalence Numbers of the equipment on your telephone line should be less than five in order to assure proper service from the telephone company. In some cases, a sum of five may not be usable on your line. If any of your telephone equipment is not operating properly, you should immediately remove it from your telephone line, as it may cause harm to the telephone network.

**WARNING:**

FCC Regulations state that changes or modifications to this equipment not expressly approved by the manufacturer could void the user's authority to operate this equipment. In the event that terminal equipment causes harm to the telephone network, the telephone company should notify the customer that service may be stopped. However, where prior notice is impractical, the company may temporarily cease service, providing that they:

- a) promptly notify the customer.
- b) give the customer an opportunity to correct the equipment problem.
- c) inform the customer of the right to bring a complaint to the Federal Communication Commission pursuant to procedures set out in FCC Rules and Regulations Subpart E of Part 68.

**You should also know that:**

- Your machine is not designed to be connected to a digital PBX system.
- If you intend to use a computer modem or fax modem on the same phone line as your machine, you may experience transmission and reception problems with all the equipment. It is recommended that no other equipment, except for a regular telephone, share the line with your machine.
- If your area experiences a high incidence of lightning or power surges, we recommend that you install surge protectors for both the power and the telephone lines. Surge protectors can be purchased from your dealer or telephone and electronic specialty stores.
- When programming emergency numbers and/or making test calls to emergency numbers, use a non-emergency number to advise the emergency service dispatcher of your intentions. The dispatcher will give you further instructions on how to actually test the emergency number.
- This machine may not be used on coin service or party lines.
- This machine provides magnetic coupling to hearing aids.
- You may safely connect this equipment to the telephone network by means of a standard modular jack, USOC RJ-11C.

# Declaration of Conformity (European Countries)

## Approvals and Certifications



The CE marking applied to this product symbolizes Samsung Electronics Co., Ltd. Declaration of Conformity with the following applicable 93/68/EEC Directives of the European Union as of the dates indicated:

**January 1, 1995:** Council Directive 73/23/EEC Approximation of the laws of the member states related to low voltage equipment.

**January 1, 1996:** Council Directive 89/336/EEC (92/31/EEC), approximation of the laws of the Member States related to electromagnetic compatibility.

**March 9, 1999:** Council Directive 1999/5/EC on radio equipment and telecommunications terminal equipment and the mutual recognition of their conformity.

A full declaration, defining the relevant Directives and referenced standards can be obtained from your Samsung Electronics Co., Ltd. representative.

## EC Certification

### Certification to 1999/5/EC Radio Equipment & Telecommunications Terminal Equipment Directive (FAX)

This Samsung product has been self-certified by Samsung for pan-European single terminal connection to the analogue public switched telephone network (PSTN) in accordance with Directive 1999/5/EC. The product has been designed to work with the national PSTNs and compatible PBXs of the European countries:

In the event of problems, you should contact the Euro QA Lab of Samsung Electronics Co., Ltd. in the first instance.

The product has been tested against TBR21. To assist in the use and application of terminal equipment which complies with this standard, the European Telecommunication Standards Institute (ETSI) has issued an advisory document (EG 201 121) which contains notes and additional requirements to ensure network compatibility of TBR21 terminals. The product has been designed against, and is fully compliant with, all of the relevant advisory notes contained in this document.



## Replacing the Fitted Plug (for UK Only)

### IMPORTANT

The mains lead for this machine is fitted with a standard (BS 1363) 13 amp plug and has a 13 amp fuse. When you change or examine the fuse, you must re-fit the correct 13 amp fuse. You then need to replace the fuse cover. If you have lost the fuse cover, do not use the plug until you have another fuse cover.

Please contact the people from you purchased the machine.

The 13 amp plug is the most widely used type in the UK and should be suitable. However, some buildings (mainly old ones) do not have normal 13 amp plug sockets. You need to buy a suitable plug adaptor. Do not remove the moulded plug.

### WARNING

**If you cut off the moulded plug, get rid of it straight away.  
You cannot rewire the plug and you may receive an electric shock if you plug it into a socket.**

### IMPORTANT WARNING: You must earth this machine.

The wires in the mains lead have the following color code:

- Green and Yellow: Earth
- Blue: Neutral
- Brown: Live

If the wires in the mains lead do not match the colors marked in your plug, do the following:

You must connect the green and yellow wire to the pin marked by the letter "E" or by the safety 'Earth symbol' or colored green and yellow or green.

You must connect the blue wire to the pin which is marked with the letter "N" or colored black.

You must connect the brown wire to the pin which is marked with the letter "L" or colored red.

You must have a 13 amp fuse in the plug, adaptor, or at the distribution board.



# **MEMO**

# 1

## GETTING STARTED

Thank you for purchasing this Samsung multifunctional product. Your machine provides printing, copying, scanning, and faxing (SCX-4216F only) functions!

This chapter gives you step-by-step instructions for setting up your machine.


This chapter includes:

- **Unpacking**
- **Understanding the Component Location**
- **Installing the Toner Cartridge**
- **Loading Paper**
- **Making Connections**
- **Turning the Machine On**
- **Changing the Display Language**
- **Setting the Paper Type and Size**
- **Using the Save Modes**


---

# Unpacking


Remove the machine and all accessories from the packing carton. Make sure that the machine has been packed with the following items:




**Toner Cartridge**




**AC Power Cord<sup>1</sup>**




**CD-ROM<sup>2</sup>**



**Quick Install Guide**



**Telephone Line Cord<sup>1</sup>**  
(only for SCX-4216F)



**TAM Lead**  
(only for SCX-4216F in UK)


1. The appearance of the power cord and the telephone line cord may differ according to your country's specifications.
2. The CD-ROM contains the MFP driver, SmarThru software, the User's Guides and the Adobe Acrobat Reader program.

---


## NOTES:

- You should use the telephone line cord which is supplied with your machine. If you are replacing it with another vendor's, it should be AWG #26 or lower gage.
  - Power cord must be plugged into a grounded power socket.
  - You can purchase and install the optional Network Print Server. For details, refer to the User's Guide supplied with your Network Print Server.
-

- 1 Remove the packing tapes from the front, back and sides of the machine.



- 2 Pull the paper tray open and remove the packing material from the tray.



## Selecting a Location

Select a level, stable place with adequate space for air circulation. Allow extra space for opening covers and trays. The area should be well-ventilated and away from direct sunlight or sources of heat, cold and humidity. Do not set the printer close to the edge of your desk or table.


### Clearance Space

**Front:** 482.6 mm (enough space so that the paper tray can be removed)

**Back:** 100 mm (enough space for ventilation)

**Right:** 100 mm


**Left:** 100 mm (enough space for ventilation)



# Understanding the Component Location

These are the main components of your machine.


## Front View



\* The figure above shows a SCX-4216F.




## Rear View














\* The figure above shows a SCX-4216F.

# Control Panel Functions


## SCX-4216F



|                       |  |  |
|-----------------------|--|--|
| 1<br>C<br>O<br>P<br>Y |  | Adjusts the brightness of the documents for the current copy job.  |
|                       |  | Selects the document type for the current copy job.  |
|                       |  | Allows you to use special copy features, such as Clone, Collation, Autofit, 2-side, N-up (multiple pages on a sheet) and Poster copying. |
|                       |  | Makes a copy smaller or larger than the original.  |
|                       |  | Selects the number of copies.  |
| 2                     |  | Displays the current status and prompts during an operation.   |
|                       |  | Turns on when the toner cartridge is empty.  |
| 3                     |  | Scrolls through the options available for the selected menu item.  |
|                       |  | Confirms the selection on the display.   |
|                       |  | Enters menu functions and scrolls through menu items.  |





|                                  |   |   |
|----------------------------------|---|---|
| <b>3</b>                         | Upper Level<br>      | Sends you back to the upper menu level.   |
|                                  | Stop / Clear<br>     | Stops an operation at any time.<br>In Standby mode, clears/cancels the copy options, such as the contrast, the image setting, the copy size and the number of copies.   |
|                                  | Start Copy / Fax<br> | Starts a job.   |
| <b>4</b>                         |                      | Dials a number or enters alphanumeric characters.   |
| <b>5<br/>F<br/>A<br/>X</b>       | Resolution<br>       | Adjusts the resolution of the documents for the current fax job.  |
|                                  | Broadcasting<br>     | Allows you to send a fax to multiple destinations.  |
|                                  | Phonebook<br>        | <ul style="list-style-type: none"> <li>Allows you to store frequently-dialed fax numbers using a one or two-digit speed dial or group number for automatic dialing and edit the stored numbers.</li> <li>Allows you to print a Phonebook list.</li> </ul> |
|                                  | Redial/Pause<br>   | Redials the last number in Standby mode or inserts a pause into a fax number in edit mode.  |
|                                  | On Hook Dial<br>   | Engages the telephone line.   |
| <b>6<br/>S<br/>A<br/>V<br/>E</b> | Toner Save<br>     | Allows you to save on toner by using less toner to print a document.  |
|                                  | Toll Save<br>      | Allows you to save on call costs by sending a fax at a preset toll-saving time. Using this feature, you can take advantage of lower long distance rates at night, for example.  |

## SCX-4016/4116




1

|   |              |   |
|---|--------------|---|
| 1 | Contrast     | Adjusts the brightness of the documents for the current copy job.   |
|   | Image        | Selects the document type for the current copy job.   |
| 2 |              | Displays the current status and prompts during an operation.  |
|   |              | Turns on when the toner cartridge is empty.   |
| 3 |              | Scrolls through the options available for the selected menu item.   |
|   | Enter        | Confirms the selection on the display.  |
|   | Menu         | Enters menu functions and scrolls through menu items.   |
|   | Upper Level  | Sends you back to the upper menu level.   |
|   | Stop / Clear | Stops an operation at any time.<br>In Standby mode, clears/cancels the copy options, such as the contrast, the image setting, copy size and the number of copies. |
|   | Start Copy   | Starts a job.   |


|   |   |  |
|---|---|--|
| 4 | <div>Special</div>         | Allows you to use special copy features, such as Clone, Collation, Autofit, 2-side, N-up (multiple pages on a sheet) and Poster copying. |
|   | <div>Reduce/Enlarge</div>  | Makes a copy smaller or larger than the original.  |
|   | <div>No.of Copy</div>      | Selects the number of copies.  |
| 5 | <div>Toner Save</div>      | Allows you to save on toner by using less toner to print a document.   |

## Installing the Toner Cartridge

- 1 Open the front cover.




- 2 Remove the starter toner cartridge from its bag. Gently shake the cartridge to distribute the toner.





Thoroughly shaking the cartridge will assure the maximum copies per cartridge.

- 3** Slide the toner cartridge into the machine until it locks into place completely.



- 4** Close the front cover.



**NOTE:** When the toner cartridge needs to be replaced, the  indicator will turn on and the "Toner Empty" message will appear on the display. To replace the toner cartridge, see page 7.7.


---

## Loading Paper


The paper tray can hold a maximum of 250 sheets of 20 lb plain paper. For copying or faxing, you can use A4-, Letter-, or Legal-sized paper only. For printing a PC file, you can use many different sizes of paper. The paper tray is preset for using Letter-sized paper.

To load a stack of Letter-sized paper:


- 1 Pull open the paper tray.




- 2 Push down on the pressure plate until it locks into position.



- 3 Fan the edges of the paper stack to separate the pages. Then tap the stack on a flat surface to even it up.




- 4** Insert the paper stack into the paper tray.




If you want to load a different sized paper, you need to adjust the paper guides. For details, see page 1.14.

- 5** Pay attention to the paper limit mark on the left inside wall of the tray. Paper overloading may cause paper jams.



- 6** Slide the paper tray back in.




After you load paper, you need to set up your machine for the paper type and size you loaded. See page 1.18 for copying and faxing or page 5.7 for PC-printing.




## Changing the Paper Size in the Paper Tray

To load longer sizes of paper, such as Legal-sized paper, you need to adjust the paper guides to extend the paper tray.


- 1 Locate the paper size to which the rear paper length guide fits. The paper sizes are marked at the bottom of the tray.



- 2 Pressing and unlatching the guide lock, slide the guide out until it locks to the mark of the paper size you want.






- 3 While squeezing the paper width guide as shown, move it toward the stack of paper until it lightly touches the side of the stack.





#### NOTES:

- Do not push the paper width guide far enough to cause the materials to warp.
- If you do not adjust the paper width guide, it may cause paper jams.



## Making Connections


### 1 If you have SCX-4016/4116:

Skip this step and proceed to Step 2.

### If you have SCX-4216F:


Plug the supplied telephone line cord into the **LINE** jack and the other end into the wall jack.

Users in the United Kingdom should plug the cord of the TAM lead into the **LINE** jack and the supplied telephone line cord into the TAM lead. Then plug the other end of the telephone line cord into the wall jack.




- 2** If you want to use a parallel printer cable, purchase only IEEE-1284 compliant parallel cable and connect it to the parallel connector on your machine.

Push the metal clips down to fit inside the notches on the cable plug.



Connecting the printer to the USB port of the computer requires a certified USB cable. You will need to buy a USB 1.1 compliant cable that is within 3 m in length. Connect it to the USB connector on your machine.



---


**NOTES:**

- You only need to connect one of the cables mentioned above.
  - If you are using a USB cable, you must be running Windows 98/Me/2000/XP, or Macintosh with OS 8.6 and the G3 processor or higher.
  - When using the USB connection, your machine provides two USB modes; Fast and Slow. Fast is the default mode. Some PC users may experience poor USB function in the default mode. If this occurs, select the Slow mode to achieve successful results. For details about changing the USB mode, see page 8.16.
-

---

## Turning the Machine On

- 1 Plug one end of the supplied three-pronged electrical type cord into the AC socket on the machine and the other end into a properly grounded AC outlet.
- 2 Press the power switch to turn the machine on. "Warming Up Please Wait" appears on the display indicating that the machine is now on.



To view your display text in another language, see below.



### CAUTIONS:

- The fusing areas at the rear part of the inside of your machine is hot when powered. Be careful not to be burned when you access this area.
- Do not disassemble the machine when it is powered. If you do, it may give you an electric shock.

---

## Changing the Display Language

To change the language that displays on the display of the control panel, follow these steps:

- 1 Press **Menu** until "Machine Setup" appears on the top line of the display.
- 2 Press the scroll button (◀ or ▶) until "Language" appears on the bottom line of the display.

- 3 Press **Enter**. The current setting appears on the bottom line of the display.
- 4 Press the scroll button (◀ or ▶) until the language you want appears on the display.
- 5 Press **Enter** to save the selection.
- 6 To return to Standby mode, press **Stop/Clear**.

---

## Setting the Paper Type and Size

After loading paper in the paper tray, you need to set the paper type and size using the control panel buttons. **These settings will apply to copy mode.** For PC-printing, you need to select the paper type and size in the application program you use.

- 1 Press **Menu**.

The display shows "Paper Setting" on the top line and the first menu item, "Paper Type," on the bottom line.

- 2 Press **Enter** to access the menu item.

- 3 Use the scroll button (◀ or ▶) to find the paper type you are using and press **Enter** to save it.

The display shows the next menu item, "**Paper Size**," on the bottom line.

- 4 Press **Enter** to access the menu item.

- 5 Press **Enter** when "Tray Paper" displays on the bottom line.

- 6 Use the scroll button (◀ or ▶) to find the paper size you are using and press **Enter** to save it.

- 7 To return to Standby mode, press **Stop/Clear**.

## Using the Save Modes

### Toner Save Mode

The Toner Save feature allows your machine to use less toner on each page. Activating this mode will extend the life of the toner cartridge longer than normal mode, but it will reduce the print quality.

To turn the Toner Save mode on or off, press **Toner Save**.

- If the button backlight is on, the Toner Save mode is active and the machine uses less toner when printing a document.
- If the button backlight is off, the Toner Save mode is deactivated and the machine prints with the normal quality.



**NOTE:** For PC-printing, you can also turn on or off the Toner Save mode in the printer properties. See page 5.20.

### Power Save Mode

Power Save mode allows your machine to reduce power consumption when it is not in actual use. You can turn this mode on by selecting the length of time for which the machine waits after a job is printed before it switches to a reduced power state.

- 1 Press **Menu** until "Machine Setup" appears on top line of the display.
- 2 Press the scroll button (◀ or ▶) until "Power Save" appears on the bottom line.
- 3 Press the scroll button (◀ or ▶) to display "On" on the bottom line and press **Enter**.

Selecting "Off" means that the Power Save mode turns off.

- 4 Press the scroll button (◀ or ▶) until the desired time settings appears.

The available options are 5, 10, 15, 30 and 45 (minutes).

- 5 Press **Enter** to save the selection.
- 6 To return to Standby mode, press **Stop/Clear**.

## CCD Power Save Mode

The scan lamp under the document glass automatically turns off when it is not in actual use to reduce power consumption and extend the lamp life. The lamp will automatically wake up after some warm-up time when you start scanning.

You can set the length of time for which the scan lamp waits after a scan job is completed before it switches to Power Save mode.

- 1 Press **Menu** until "Machine Setup" appears on top line of the display.
- 2 Press the scroll button (◀ or ▶) until "CCD Power Save" appears on the bottom line.
- 3 Press the scroll button (◀ or ▶) until the desired time setting appears on the bottom line.

The available time options are 1, 4, 8 and 12 (hours). Selecting "Off" means that the lamp always turns off.

- 4 Press **Enter** to save the selection.
- 5 To return to Standby mode, press **Stop/Clear**.



# 2

## INSTALLING SOFTWARE

This chapter gives you information for installing the supplied Samsung software. You must install the Samsung software to use your machine as a printer and a scanner.

This chapter includes:

- **About Samsung Software**
- **System Requirements**
- **Installing Samsung Software in Windows**
- **Uninstalling Samsung Software**



---

## About Samsung Software

You must install software using the supplied CD-ROM after you have set up your machine and connected it to your computer. The CD-ROM includes:

- Samsung software
- User's Guides
- Adobe Acrobat Reader

The CD-ROM provides you with the following software:

### Windows MFP Driver

To use your machine as a printer and scanner in Windows, you must install the MFP driver. For information about installing the MFP driver in Windows, see page 2.4.

### Macintosh Printer Driver

You can use your machine with Macintosh. For information about installing the printer driver and printing documents from a Macintosh, see Appendix A, "Printing from a Macintosh."

### Remote Control Panel

This Windows-based program is only available for SCX-4216F. It is automatically installed when you install the MFP driver. For information about using the program, refer to the Facsimile User's Guide.

### USB Driver

You must first install the USB driver for the USB connection in Windows 98/Me. For information about installing the USB driver, see page 2.8. In Windows 2000/XP, the USB port is provided so that you don't have to install the USB driver.

### SmarThru Software

SmarThru is the accompanying software for your multifunctional machine. SmarThru contains a powerful image editor that allows you to edit images in many ways and also includes powerful Internet mail client software.

With SmarThru, you can save the scanned images in a dedicated storage area for subsequent editing, sending via e-mail or fax, printing and processing by other programs of your choice.

## OCR Software (AnyPage Lite)

OCR (Optical Character Recognition) is software that has the ability to recognize most character formats so that a scanned document can be read and edited with word processing software.

---

## System Requirements

Before you begin, ensure that your system meets the minimum requirements.

### Supported Operating System

- Windows 95 OSR2
- Windows 98/Windows 98 SE
- Windows Me
- Windows NT 4 Workstation or Server with Service Pack 3
- Windows 2000 Professional or Advanced Server
- Windows XP Home edition or Professional.

### Minimal Requirements

- Disk space: 120 MB for installation
- Memory: 64 MB
- CPU: Pentium II 233 or higher
- Required software: Internet Explorer 4.01

### Recommended

- Disk space: 220 MB for installation
- Memory: 128 MB
- CPU: Pentium II 400 or higher
- Required software: Internet Explorer 5.5



---

### NOTES:

- For Windows NT 4.0/2000/XP, the system administrator should install the software.
  - Windows 95 versions prior to OSR2 are not recommended due to incompatibility with OLE/COM libraries.
-

# Installing Samsung Software in Windows



## NOTES:

- Cancel the "New Hardware Found" window when your computer boots up.
- Make sure that your machine is plugged in and connected to your computer's parallel port or USB port **before installing software**. Windows 95 and Windows NT 4.0 do not support the USB connection.


### 1 Insert the supplied CD-ROM into your CD-ROM drive.

The CD-ROM should automatically run and an installation window appears.

If the installation window does not appear, click **Start** and then **Run**. Type **X:Autorun.exe**, replacing "**X**" with the letter of your drive and click **OK**.

### 2 If you are asked to select the language, choose the desired language.


### 3 Click **Install the Samsung Software on your PC**.




- 4 Click **Next**.
- 5 Follow the on-screen instructions and click **Next**.
- 6 Click **Next**.
- 7 Select the installation type and click **Next**.

The software installation supports three types of setup:

- **Typical:** Program will be installed with the most common options and is recommended for most users.
- **Compact:** Only the MFP driver will be installed.
- **Custom:** You may choose the options you want to install.




If you select the Custom installation, you may choose the components you want to install.




- **SmartThru Software:** to scan and edit images and to work with electronic documents.
- **OCR Software:** AnyPage Lite software to enable OCR.
- **MFP Driver:** to print and scan.

- 8 Choosing the **SmarThru networking** option allows you to share the modems on other computer in your network, and the scan device or to access similar devices on other computers.

**Stand-alone configuration** does not allow you to use any networking features, such as Remote Fax or Remote Scan service.




If you selected **SmarThru networking**, you can elect to install it as a Server, a Client or both.



The **Server** option allows you to share a local fax modem and/or a scanner over a LAN. You can control sharing by managing a remote service user. The **Client** option allows you to use Remote Fax or Remote Scan services provided by a SmarThru Server over a LAN. You need to have a client account provided by the server. For details on Remote Fax/Scan Services, refer to the SmarThru User's Guide.


## 9 Click **Next**.



## 10 If you want to register yourself as a user of the Samsung printer, click **Next**. You can access the Samsung web site.

If not, remove the check mark and click **Next**.

## 11 When the installation is complete, click **Finish**.



If your computer does not shut down and restart automatically, you must shut it down manually and restart it before the changes will be saved.



**NOTE:** When you install the software, the Digital Signature Not Found window appears in Windows 2000 and Windows XP. Click **OK** in Windows 2000 and click **Continue Anyway** in Windows XP.

## Installing the USB Driver in Windows 98/Me

- 1 Connect the printer to your computer using the USB cable and turn them on. For further details, see page 1.16.
- 2 The Add New Hardware Wizard window appears. Click **Next**.
- 3 Place the CD-ROM in the CD-ROM drive and check **Search for the best driver for your device** and click **Next**.
- 4 Check **CD-ROM drive** and click **Browse**, and choose **x:\USB** (where **x** is the drive letter for the CD-ROM drive). Click **Next**.



- 5 Click **Next**. The USB driver is installed.
- 6 When the installation is complete, click **Finish**.
- 7 When the language selection window appears, select the appropriate language.



**NOTE:** If you already installed the printer software, this window does not appear.

- 8 Follow the instructions on the window to complete the printer software installation. For further details, see page 2.4.



#### NOTES:


- If you want to use your machine with a parallel cable, remove the USB cable and connect the parallel cable. Then reinstall the MFP driver.
- If your machine does not work properly, reinstall the MFP driver.

## Uninstalling Samsung Software

Uninstall is required if you are upgrading the software or if your installation fails. You can uninstall all software including SmarThru and MFP driver, using the CD-ROM or uninstall the desired item using the Windows unInstallShield.

### Uninstalling the MFP Driver

- 1 From the **Start** menu, select **Programs**, and then select **Samsung SCX-4x16 Series**.



- 2 You can select a component in the MFP driver to uninstall individually.

If you want to uninstall the printer driver, select **Printer Driver Uninstall**.

If you want to uninstall the twain driver, select **Twain Driver Uninstall**.

For SCX-4216F, if you want to uninstall the Remote Control Panel, select **Remote Control Panel Uninstall**.



- 3 If your computer asks you to confirm your selection, click **Yes** or **OK**.

The selected driver and all of its components are removed from your computer.


- 4 When the uninstallation is done, click **Finish** or **OK**.

## Uninstalling Samsung SmarThru




**NOTE:** Before beginning uninstallation, ensure that all applications are closed on your computer. A system reboot is required after the software is uninstalled.

- 1 From the **Start** menu, select **Programs**.
- 2 Select **Samsung SmarThru**, and then select **SmarThru 3 Uninstall**.




- 3 When your computer asks you to confirm your selection, click **Yes**. The Uninstall Options window appears.



Uninstall options are:

- **Backup and delete:** Backs up all your data and options to a safe place. It then removes the SmarThru system including the data.
- **Delete:** Deletes all the SmarThru data and options. No backup or copying takes place. Be careful while using this option as you can easily lose your data.
- **Leave intact:** Uninstalls SmarThru software leaving data and options intact. This can be useful, if, for example, you decide to install the Stand Alone configuration over the SmarThru Networking. In this case, uninstall Samsung SmarThru having the **Leave intact** option set and install the SmarThru Stand Alone configuration.

- 4 After selecting the uninstall option, click **Next**.
- 5 When the uninstallation is done, the message window recommends restarting your computer. Click **OK**.
- 6 Click **Finish**.



If your computer does not shut down and restart automatically, you must shut it down manually and restart it before the changes will be saved.

## Using the CD-ROM


You can uninstall all of the MFP driver, the Remote Control Panel and the SmarThru software with the CD-ROM you have used to install them.

- 1 Insert the supplied CD-ROM into your CD-ROM drive.

The CD-ROM should automatically run and an installation window appears.

If the installation window does not appear, select **Run** from the **Start** menu and then type **X:Autorun.exe**, replacing "X" with the letter of your drive and click **OK**.

- 2 If you are asked to select the language, choose the desired language.
- 3 Click **Uninstall the Samsung Software on your PC**.



- 4 Follow the on-screen instructions to complete the uninstallation.
- 5 When the uninstallation is done, click **Finish**.

If your computer does not shut down and restart automatically, you must shut it down manually and restart it before the changes will be saved.



# 3

## PAPER HANDLING

This chapter introduces you to the basics of selecting print materials and loading them into your machine.

This chapter includes:

- **Selecting Print Materials**
- **Selecting an Output Location**
- **Loading Paper in the Paper Tray**
- **Using the Bypass Tray**

## Selecting Print Materials

Always use print materials that meet the guidelines for use with this machine. Using print materials that are not recommended may cause paper jams or print quality problems.

### Size, Input Sources and Capacities

| Size (mm/in.)   | Input Source/Capacity <sup>1</sup>  |   |
|---|---|---|
|   | Paper Tray  | Bypass Tray   |
| <b>Plain paper</b><br>Letter (215.9 x 279/8.5 x 11)<br>A4 (210 x 297/8.27 x 11.69)<br>Folio (215.9 x 330.2/8.5 x 13)<br>Legal (215.9 x 355.6/8.5 x 14)<br>Executive (184.2 x 266.7/7.25 x 10.5)<br>A5 (148 x 210/5.83 x 8.27)<br>A6 (105 x 148/4.13 x 5.88) | YES/250<br>YES/250<br>YES/250<br>YES/250<br>YES/250<br>YES/250<br>YES/250 | YES/1<br>YES/1<br>YES/1<br>YES/1<br>YES/1<br>YES/1<br>YES/1 |
| <b>Envelopes</b><br>No.9 (98.4 x 225.4/3.88 x 8.88)<br>No.10 (104.8 x 241.3/4.13 x 9.5)<br>DL (110 x 220/4.33 x 8.66)<br>C5 (162 x 229/6.38 x 9.02)<br>C6 (114 x 162/4.49 x 6.38)<br>B5 (176 x 250/6.93 x 9.84)<br>No.7 3/4 (98.4 x 190.5/3.88 x 7.5)       | NO/0<br>NO/0<br>NO/0<br>NO/0<br>NO/0<br>NO/0<br>NO/0                      | YES/1<br>YES/1<br>YES/1<br>YES/1<br>YES/1<br>YES/1          |
| <b>Labels<sup>2</sup></b><br>Letter (215.9 x 279/8.5 x 11)<br>A4 (210 x 297/8.27 x 11.69)   | NO/0<br>NO/0  | YES/1<br>YES/1  |
| <b>Transparency films<sup>2</sup></b><br>Letter (215.9 x 279/8.5 x 11)<br>A4 (210 x 297/8.27 x 11.69)   | NO/0<br>NO/0  | YES/1<br>YES/1  |
| <b>Card stocks<sup>2</sup></b><br>A6 card (105 x 148/4.13 x 5.88)<br>Post Card (101.6 x 152.4/4 x 6)<br>Hagaki (100 x 148/3.94 x 5.83)  | NO/0<br>NO/0<br>NO/0  | YES/1<br>YES/1<br>YES/1                                     |

1. Maximum capacity may be reduced depending on paper thickness.

2. If you are experiencing excessive jamming, load one sheet at a time through the Bypass tray.

## Guidelines for Paper and Special Materials

When selecting or loading paper, envelopes, or other special materials, keep these guidelines in mind:


- Attempting to print on damp, curled, wrinkled, or torn paper can cause paper jams and the poor print quality.
- Use only high quality copier grade paper. Avoid paper with embossed lettering, perforations, or texture that is too smooth or too rough. Paper jams may occur.
- Store paper in its ream wrapper until ready to use. Place cartons on pallets or shelves, not on the floor. Do not place heavy objects on top of the paper, whether it is packaged or unpackaged. Keep it away from moisture, or other conditions that can cause it to wrinkle or curl.
- During storage, you should use moisture-proof wrap, such as any plastic container or bag, to prevent dust and moisture from contaminating your paper.
- Always use paper and other materials that conform with the specifications listed under "Paper Specifications" on page B.6.
- Use only well-constructed envelopes with sharp, well creased folds.
  - DO NOT use envelopes with clasps and snaps.
  - DO NOT use envelopes with windows, coated lining, self-adhesive seals, or other synthetic materials.
  - DO NOT use damaged or poorly made envelopes.
- It is recommended that you load special paper types one sheet at a time.
- Only use materials specifically recommended for use in laser printers.
- To prevent special materials, such as transparencies and label sheets from sticking together, remove them as they prints out.
- Place transparencies on a flat surface after removing them from the machine.
- Do not leave transparencies in the paper tray for long periods of time. Dust and dirt may accumulate on them resulting in spotty printing.
- To avoid smudging caused by fingerprints, handle transparencies and coated paper carefully.
- To avoid fading, do not expose the printed transparencies to prolonged sunlight.
- Store unused materials at temperatures between 15 °C and 30 °C (59 °F to 86 °F). The relative humidity should be between 10 % and 70 %.

- Verify that your labels' adhesive material can tolerate fusing temperature of 200 °C (392° F) for 0.1 second.
- Make sure that there is no exposed adhesive material between labels. Exposed areas can cause labels to peel off during printing, which can cause paper jams. Exposed adhesive can also cause damage to machine components.
- Do not load a sheet of labels through the machine more than once. The adhesive backing is designed for one pass through the machine.
- Do not use labels that are separating from the backing sheet or are wrinkled, bubbled, or otherwise damaged.

---

## Selecting an Output Location

The machine has two output locations; the rear output slot (face up) and the front output tray (face down).



To use the front output tray, make sure that the rear cover is closed. To use the rear output slot, open the cover.




---

### NOTES:

- If paper coming out of the front output tray has problems, such as excessive curl, try printing to the rear output slot.
  - To avoid paper jams, do not open or close the rear cover while the machine is printing.
-

## Printing to the Front Output Tray *(Face down)*


The front output tray collects printed paper face-down, in correct order. The tray should be used for most print jobs.



3

## Printing to the Rear Output Slot *(Face up)*

Using the rear output slot, paper comes out of the machine face-up.




Printing from the Bypass tray to the rear output slot provides the **straight paper path**. Using the rear output slot might improve the output quality with the following:

- envelopes
- labels
- small custom-sized paper
- postcards
- transparencies




## To use the rear output slot:

- 1 Open the rear cover by pulling it upward.



**CAUTION:** The fusing area at the rear part of the inside of your machine is hot when powered. Be careful not to be burned when you access this area.

- 2 If you do not want to stack the printed pages on the rear output slot, close the rear cover. The pages will stack on the front output tray.




---


## Loading Paper in the Paper Tray

The paper tray can hold a maximum of 250 sheets of 20 lb plain paper. For copying or faxing, you can use A4-, Letter- or Legal-sized paper only. For PC-printing, you can use many different sizes of paper; see page 3.2.


The paper level indicator on the front of the paper tray shows the amount of paper currently left in the tray. When the tray is empty, the indicator of the bar is lowered.



To load paper, pull open the paper tray and load paper with the print side face down.



You can load letterhead paper with the design side face down. The top edge of the sheet with the logo should be placed at the front side of the tray.




For details about loading paper in the paper tray, see "Loading Paper" on page 1.12.



#### NOTES:

- If you experience problems with paper feed, place the paper in the Bypass tray.
- You can load up to 150 sheets of previously printed paper. The printed side should be facing up with an uncurled edge at the top side. If you experience problems with paper feed, turn the paper around. Note that the print quality is not guaranteed.



## Using the Bypass Tray

Use the Bypass tray to print transparencies, labels, envelopes or postcards in addition to making quick runs of paper types or sizes that are not currently loaded in the paper tray.


Acceptable print materials are plain paper with sizes ranging from 100 x 148 mm (3.9 x 5.8 in.) to Legal, 216 x 356 mm (8.5 x 14 in.), the largest size acceptable, and weighing between 16 lb and 32 lb.



#### NOTES:


- Always load only the print materials specified in the Specifications on page B.6 to avoid paper jams and print quality problems.
- Flatten any curl on postcards, envelopes and labels before loading them into the Bypass tray.

- 1 Load a sheet of the print material with the print side face up and into the center of the tray.




For transparencies, hold the transparencies by the edges and avoid touching the print side. Oils from your fingers that are deposited on the transparency can cause print quality problems.

For envelopes, load a sheet with the flap side face down and with the stamp area on the top left side.




- 2 Adjust the paper guide to the width of the print material.




The machine picks up the material from the tray and begins printing.



**NOTE:** When printing on previously printed paper from the Bypass tray, the printed side should be facing down with an uncurled edge to the machine. If you experience problems with paper feed, turn the paper around.



- 3 Open the rear cover to use the rear output slot.



- 4 After printing, close the rear cover.

## Setting the Paper Type and Size for the Bypass Tray

After loading paper in the Bypass tray, you need to set the correct paper type and size using the control panel buttons. **These settings will apply to copy mode.** For PC-printing, you need to select the paper size in the application program you use.

To set the paper size for the Bypass tray:

- 1 Press **Menu**.

The display shows "Paper Setting" on the top line and the first item, "Paper Type," on the bottom line.

- 2 Press **Enter** to access the menu item.

- 3 Use the scroll button (◀ or ▶) to find the paper type you are using and press **Enter** to save it.

The display shows the next menu item, "Paper Size," on the bottom line.

- 4 Press **Enter** to access the menu item.

- 5 Use the scroll button (◀ or ▶) to display "Bypass Paper" on the bottom line. Press **Enter** to access the menu item.

- 6 Use the scroll button (◀ or ▶) to find the paper size you are using and press **Enter** to save it.

- 7 To return to Standby mode, press **Stop/Clear**.



# 4

## COPYING

This chapter gives you step-by-step instructions for copying documents.

This chapter includes:

- **Loading Paper for Copying**
- **Making Copies on the Document Glass**
- **Making Copies from the Automatic Document Feeder (For SCX-4116/4216F)**
- **Setting Copy Options**
- **Using Special Copy Features**
- **Changing the Default Settings**
- **Setting the Time Out Option**

---

## Loading Paper for Copying


You can copy a document to A4-, Letter- or Legal-sized paper.

The instructions for loading print materials are the same whether you are printing, faxing or copying. For further details, see page 1.12 for loading in the paper tray and page 3.8 for loading in the Bypass tray.


---

## Making Copies on the Document Glass

- 1 Lift and open the document cover.



- 2 Place the document **face down** on the document glass and align it with the registration guide on the rear left corner of the machine.





---

**NOTE:** For SCX-4116/4216F, make sure that no other documents are in the ADF (Automatic Document Feeder). If a document is detected in the ADF, it has priority over the document on the document glass.

---

**3** Close the document cover.



---

**NOTES:**

- Leaving the cover open while copying may affect the copy quality and toner consumption.
  - If you are copying a page from a book or magazine, lift the cover until its hinges are caught by the stopper and then close the cover. If the book or magazine is thicker than 30 mm, start copying with the cover open.
- 

**4** Customize the copy settings including number of copies, copy size, the contrast and the image type by using the control panel buttons. See "Setting Copy Options" on page 4.5.

To clear the settings, use the **Stop/Clear** button.

**5** If necessary, you can use special copy features, such as Auto Fit, Clone and 2-side copying.

**6** Press **Start Copy** or **Start Copy/Fax** to begin copying. The display shows the copy processing.



---

**NOTES:**

- You can cancel the copy job during an operation. Press **Stop/Clear**, and the copying will stop.
  - Dust on the document glass may cause black spots on the printout. Keep it always clean.
-



---

## Making Copies from the Automatic Document Feeder *(For SCX-4116/4216F)*


Using the ADF (Automatic Document Feeder), you can load up to 30 documents (75 g/m<sup>2</sup>, 20lb) in one job.

When you use the ADF:


- Do not load documents smaller than 142 x 148 mm or larger than 216 x 356 mm.
- Do not attempt to feed the following types of documents:
  - carbon-paper or carbon-backed paper
  - coated paper
  - onion skin or thin paper
  - wrinkled or creased paper
  - curled or rolled paper
  - torn paper
- Remove all staples and paper clips before loading documents.
- Make sure any glue, ink or correction fluid on the paper is completely dry before loading documents.
- Do not load documents containing different sizes or weights of paper.

If you want to make copies from booklet, pamphlet, transparencies or documents having other unusual characteristics, use the document glass to load the document; see page 4.2.

- 1** Load the documents up to 30 pages **face up** into the ADF and adjust the document guides to the document size.



- 2 Make sure that the bottom of the document stack matches the paper size marked on the document tray.



- 3 Customize the copy settings including number of copies, copy size, contrast and image type by using the control panel buttons. See "Setting Copy Options" on page 4.5.

To clear the settings, use the **Stop/Clear** button.

- 4 If necessary, you can use special copy features, such as Collation and 2 or 4 up-copying.
- 5 Press **Start Copy** or **Start Copy/Fax** to begin copying. The display shows the copy processing.



**NOTE:** Dust on the ADF glass may cause black lines on the printout. Keep it always clean.

---

## Setting Copy Options

The buttons on the control panel let you make all the basic copy options; contrast, image type, copy size and number of copies. Set the following options for the current copy job before pressing **Start Copy** or **Start Copy/Fax** to make copies.



**NOTE:** If you press **Stop/Clear** while you set the copy options, all of the options you have set for the current copy job will be canceled and return to their default status. Or, they will automatically return to their default status after copying.

## Contrast

If you have an original document containing faint markings and dark images, you can adjust the brightness to make a copy that is easier to read.

To adjust the contrast, press **Contrast**.

Each time you press the button, the LED labeled with the selected mode turns on.

You can choose from the following contrast modes:

- **Lighten**: works well with dark print.
- **Normal**: works well with standard typed or printed documents.
- **Darken**: works well with light print or faint pencil markings.

## Image

The Image setting is used to improve the copy quality by selecting the document for the current copy job.

To select the image type, press **Image**.

Each time you press the button, the LED labeled with the selected mode turns on.

You can choose from the following image modes:

- **Text**: Use for documents containing mostly text.
- **Mixed**: Use for documents with mixed text and graphics.
- **Photo**: Use when the originals are photographs.



---

**NOTE:** When you copy a document containing color on the background, such as a newspaper or a catalog, from the document glass using the Mixed mode, the machine will automatically remove the background color. If you want to include the background color in your copy, load the document about 5 mm away from the guideline on the document glass or change the Contrast setting.

---

## Reduced/Enlarged Copy

Using the **Reduce/Enlarge** button, you can reduce or enlarge the size of a copied image, from 25% to 400% when you copy original documents from the document glass or from 25% to 100% from the ADF. Note that the zoom rate available is different depending on the document loading method.

To select from the predefined copy sizes:

**1** Press **Reduce/Enlarge**.

The default setting appears on the bottom line of the display.

**2** Use **Reduce/Enlarge** or the scroll button (◀ or ▶) to find the desired size setting.

**3** Press **Enter** to save the selection.

To fine-tune the size of copies:

**1** Press **Reduce/Enlarge**.

**2** Press **Reduce/Enlarge** or the scroll button (◀ or ▶) until "Custom:25-100%," or "Custom:25-400%" (for SCX-4116/4216F) displays on the bottom line.

**3** Enter the desired size using the number keypad. The selected number appears on the display.

**4** Press **Enter** to save the selection.



**NOTE:** When you make a reduced copy, black lines may appear at the bottom of your copy.

## Number of Copies

Using the **No. of Copy** button, you can select the number of copies from 1 to 99.

**1** Press **No. of Copy**.

**2** Enter the number of copies using the number keypad. The selected number appears on the display.

**3** Press **Enter** to save the selection.

---

## Using Special Copy Features

You can use the following copy features using the **Special** button on the control panel:

- **Auto Fit:** Automatically reduces or enlarges the original image to fit on the paper currently loaded in the machine. See below.
- **Clone:** Prints multiple image copies from the original document on a single page. The number of images is automatically determined by the original image size. See page 4.9.
- **Collation:** Sorts the copy job. For example, if you make 2 copies of 3 page documents, one complete 3 page document will print followed by the second complete document. See page 4.10.
- **2-Side:** Prints 2-sided original document on one sheet of paper. See page 4.10.
- **2/4-Up:** Prints 2/4 original images reduced to fit onto one sheet of paper. See page 4.11.
- **Poster:** Prints an image onto 9 sheets of paper (3x3). You can paste the printed pages together to make one poster-size document. See page 4.12.




---

**NOTE:** Some features may not be available depending on where you loaded the document, on the document glass or in the Automatic Document Feeder (for SCX-4116/4216F).

---

### Auto Fit Copying



This special copy mode can be applied when you load document only using the document glass. For SCX-4116/4216F, if a document is detected in the ADF, the Auto Fit does not work.

- 1 Load the document to be copied on the document glass, and close the cover.
- 2 Press **Special Copy**. The display shows "Auto Fit" on the bottom line.
- 3 Press **Enter** to save the selection.




- 4 If necessary, customize the copy settings including number of copies, contrast and image type by using the control panel buttons. See "Setting Copy Options" on page 4.5.



**NOTE:** You cannot adjust the copy size using the **Reduce/Enlarge** button while the Auto Fit copying is enabled.


- 5 Press **Start Copy** or **Start Copy/Fax** to begin copying.

## Clone Copying



This special copy mode can be applied when you load document only using the document glass. For SCX-4116/4216F, if a document is detected on the ADF, the Clone copying feature does not work.

- 1 Load the document to be copied on the document glass, and close the cover.
- 2 Press **Special**. The display shows "Auto Fit" on the bottom line.
- 3 Press **Special** or the scroll button (◀ or ▶) until "Clone" displays on the bottom line.
- 4 Press **Enter** to save the selection.




- 5 If necessary, customize the copy settings including number of copies, contrast and image type by using the control panel buttons. See "Setting Copy Options" on page 4.5.



**NOTE:** You cannot adjust the copy size using the **Reduce/Enlarge** button while making a clone copy.

- 6 Press **Start Copy** or **Start Copy/Fax** to begin copying.

## Collation Copying




The Collation copying feature is available only when you load documents in the ADF.

- 1 Load the documents to be copied in the ADF.
- 2 Press **Special**. The display shows "Auto Fit" on the bottom line.
- 3 Press **Special** or the scroll button (◀ or ▶) until "Collation" displays on the bottom line.
- 4 Press **Enter** to save the selection.



- 5 If necessary, customize the copy settings including number of copies, copy size, contrast and image type by using the control panel buttons. See "Setting Copy Options" on page 4.5.
- 6 Press **Start Copy** or **Start Copy/Fax** to begin copying.

## 2-side Copying



You can copy a 2-sided document on one page of A4, Letter or Legal-sized paper.

When you copy using this feature, the machine prints one side on the upper half of the paper and the other side on the lower half without reducing the original. This feature is helpful for copying a small-sized document, such as a name card.

If the original document is larger than the printable area, some portions may not be printed.

This special copy mode can be applied when you load document only using the document glass. For SCX-4116/4216F, if a document is detected in the ADF, the 2-side copying feature does not work.

- 1 Load the document to be copied on the document glass, and close the cover.
- 2 Press **Special**. The display shows "Auto Fit" on the bottom line.

- 3 Press **Special** or the scroll button (◀ or ▶) until "2-Side" displays on the bottom line.
- 4 Press **Enter** to save the selection.



- 5 If necessary, customize the copy settings including number of copies, contrast and image type by using the control panel buttons. See "Setting Copy Options" on page 4.5.



**NOTE:** You cannot adjust the copy size by using the **Reduce/Enlarge** button for 2-side copying.

- 6 Press **Start Copy** or **Start Copy/Fax** to begin copying.


Your machine begins scanning the front side.

- 7 When "Set Backside" displays on the bottom line, open the document cover and flip the document over. Close the cover.



**NOTE:** If you press the **Stop** button or if no buttons are pressed for about 30 seconds, the machine cancels the copy job and returns to Standby mode.

- 8 Press **Start Copy** or **Start Copy/Fax** again.



▲ 2-up copying



▲ 4-up copying


## 2-up or 4-up Copying

The 2 or 4-up copying feature is available only when you load documents in the ADF.

- 1 Load the documents to be copied in the ADF.
- 2 Press **Special**. The display shows "Auto Fit" on the bottom line.
- 3 Press **Special** or the scroll button (◀ or ▶) until "2-Up" or "4-Up" displays on the bottom line.



- 4 Press **Enter** to save the selection.



▲ When you select "4-Up"

- 5 If necessary, customize the copy settings including number of copies, contrast and image type by using the control panel buttons. See "Setting Copy Options" on page 4.5.




**NOTE:** You cannot adjust the copy size using the **Reduce/Enlarge** button while making a 2 or 4-up copy.

- 6 Press **Start Copy** or **Start Copy/Fax** to begin copying.




**NOTE:** 2-up copy reduces your original document by 50 %. 4-up copy reduces the document by the following rates depending on the paper loaded: 76 % for Letter, 81 % for A4 and 95 % for Legal.

## Poster Copying



This special copy mode can be applied when you load document only using the document glass. For SCX-4116/4216F, if a document is detected in the ADF, the Poster copying feature does not work.

- 1 Load the documents to be copied on the document glass and close the cover.
- 2 Press **Special**. The display shows "Auto Fit" on the bottom line.
- 3 Press **Special** or the scroll button (◀ or ▶) until "Poster" displays on the bottom line.
- 4 Press **Enter** to save the selection.



- 5 If necessary, customize the copy settings including number of copies, contrast and image type by using the control panel buttons. See "Setting Copy Options" on page 4.5.



**NOTE:** You cannot adjust the copy size using the **Reduce/Enlarge** button while making a poster.

- 6 Press **Start Copy** or **Start Copy/Fax** to begin copying.

Your original document is divided into 9 portions. Each portion is scanned and printed one by one in the following order:

|   |   |   |
|---|---|---|
| 1 | 2 | 3 |
| 4 | 5 | 6 |
| 7 | 8 | 9 |

## Changing the Default Settings

The copy options, including contrast, image quality, copy size and number of copies, can be set to the most frequently used modes. When you copy a document, the default settings are used unless they are changed by using the corresponding buttons on the control panel.

To create your own default settings:

- 1 Press **Menu** on the control panel until "Copy Setup" appears on the top line of the display.  
  
The first menu item, "Change Default", appears on the bottom line.
- 2 Press **Enter** to access the menu item. The first setup option, "Contrast," appears on the bottom line.
- 3 Press the scroll button (◀ or ▶) to scroll through the setup options.
- 4 When the desired option appears, press **Enter** to access the option.
- 5 Change the setting using the scroll button (◀ or ▶) or enter the desired value using the number keypad.
- 6 Press **Enter** to save the selection.
- 7 Repeat steps 3 through 6, as needed.
- 8 To return to Standby mode, press **Stop/Clear**.



#### NOTES:

- While you set copy options, pressing **Stop/Clear** cancels the changed settings and restores their default status.
- If you use the **Copy Setup** option in the **Clear Memory** menu, your own default settings are reset to the factory default settings.

---

## Setting the Time Out Option

You can set the time the machine waits before it restores the default copy settings, if you do not start copying after changing them on the control panel.

- 1 Press **Menu** on the control panel until "Copy Setup" appears on the top line of the display.
- 2 Press the scroll button (◀ or ▶) to display "Timeout" on the bottom line.
- 3 Press **Enter** to access the menu item.
- 4 Press the scroll button (◀ or ▶) until the desired status appears on the display.

You can select from 15, 30, 60 and 180 (seconds).  
Selecting "Off" means that the machine does not restore the default settings until you press **Start Copy** or **Start Copy/Fax** to begin copying, or **Stop/Clear** to cancel.

- 5 Press **Enter** to save the selection.
- 6 To return to Standby mode, press **Stop/Clear**.



# 5

## PRINTING

This chapter explains how to print your documents in Windows and how to use the print settings.

This chapter includes:

- **Printing a Document**
- **Setting Paper Properties**
- **Printing Multiple Pages on One Sheet of Paper (N-Up Printing)**
- **Printing a Reduced or Enlarged Document**
- **Fitting Your Document to a Selected Paper Size**
- **Printing Posters**
- **Using Watermarks**
- **Using Overlays**
- **Setting Graphic Properties**
- **Setting Up the Locally Shared Printer**

---

## Printing a Document

The following procedure describes the general steps required for printing from various Windows applications. The exact steps for printing a document may vary depending on the application program you are using. Refer to your software application's User's Guide for the exact printing procedure.




**NOTE:** For detailed information about printing from a Macintosh computer, see Appendix A.

---

- 1 Open the document you want to print.
- 2 Select **Print** from the **File** menu.

The Print window is displayed. It may look slightly different depending on your application.

The basic print settings are selected within the Print window. These settings include the number of copies and print range.




▲ Windows 98

- 3 To take advantage of the printer features provided by your machine, click **Properties** in the application's print window and go to Step 4.

If you see **Setup**, **Printer** or **Options**, click that button instead. Then click **Properties** in the next screen.

- 4 Now you see the Samsung SCX-4x16 Series Properties window, which allows you to access all of information you will need when using your machine.

The **Layout** tab is first displayed.




If necessary, select the **Orientation** option.

The **Orientation** option allows you to select the direction in which information is printed on a page.

- **Portrait** prints across the width of the page, letter style.
- **Landscape** prints across the length of the page, spreadsheet style.
- If you want to rotate the page in 180 degrees, select **Rotate 180 Degrees**.



▲ Landscape



▲ Portrait

- 5 From the **Paper** tab, select the paper source, size and type. For further details, see page 5.7.

- 6 If necessary, you can set in what sequence the pages will be printed from the **Extra** tab. Select the required print order from the **Print Order** drop-down list.
  - **Normal**: Your machine prints in normal order.
  - **Reverse All Pages**: Your machine prints all pages in reversed order. This setting is helpful when you are using the rear output slot.
  - **Print Odd Pages**: Your machine prints only the odd pages of the document.
  - **Print Even Pages**: Your machine prints only the even pages of the document.
- 7 Click other tabs on the top of the Samsung SCX-4x16 Series Properties window to access other features, if needed.
- 8 When you finish setting the properties, click **OK** until the Print window is displayed.
- 9 Click **OK** to start printing.



---

**Notes:**

- Most Windows applications will override settings you specified in the printer driver. Change all of the print settings available in the software application first, and change any remaining settings using the printer driver.
  - The settings you change remain in effect only while you are using the current program. To make your changes permanent, make them in the **Printers** folder. Follow these steps:
    1. Click the Windows **Start** menu.
    2. For Windows 95/98/Me/NT 4.0/2000, select **Settings** and then **Printers**.  
For Windows XP, select **Printers and Faxes**.
    3. Select the **Samsung SCX-4x16 Series** printer.
    4. Click the right mouse button on the printer icon and:
      - For Windows 95/98/Me, select **Properties**.
      - For Windows 2000/XP, select **Print Setup** or select **Properties** and click **Printing Preferences**.
      - For Windows NT 4.0, select **Document Default**.
    5. Change the settings on each tab and click **OK**.
-

## Canceling a Print Job

There are two ways to cancel a print job:

### To stop a print job from the control panel:


Press the **Stop/Clear** button.

Your machine will finish printing the page that is moving through the machine and delete the rest of the print job. Pressing the button cancels only the current job. If more than one print job is in the machine's memory, you need to press the button once for each job.



### To stop a print job from the Printers folder:

- 1 From the Windows **Start** menu, select **Settings**.
- 2 Select **Printers** to open the Printers window and double-click the **Samsung SCX-4x16 Series** icon.
- 3 From the **Document** menu, select **Cancel Printing** (Windows 9x/Me) or **Cancel** (Windows NT 4.0/2000/XP).



▲ Windows 98



**NOTE:** You can access this window simply by double-clicking the printer icon at the bottom right corner of the Windows desktop.




## Using a Favorite Setting

The **Favorites** option, which is visible on each properties tab, allows you to save the current properties settings for future use.

To save a Favorites item:

- 1 Change the settings on each tab, as needed.
- 2 Enter a name for the item in the **Favorites** input box.



- 3 Click **Save**.

To use a saved setting, select it from the **Favorites** drop-down list.

To delete a favorite setting item, select it from the list and click **Delete**.

You can also restore the printer driver's default settings by selecting **<Printer Default>** from the list.

## Using Help


Your machine has a help screen that can be activated by the **Help** button in the printer's properties window. These help screens give detailed information about the printer features provided by the printer driver.

You can also click **?** from the upper right hand corner, and then click on any setting.

# Setting Paper Properties

Use the following options to set the paper handling needs when you access the printer properties. See page 5.2 for more information about accessing printer properties.


Click the **Paper** tab to access many paper properties.



| Property        | Description  |
|-----------------|--|
| ① <b>Copies</b> | <b>Copies</b> allows you to choose the number of copies to be printed. You can enter up to 999.  |
| ② <b>Size</b>   | <p>The <b>Size</b> option allows you to choose the size of paper loaded in the tray.</p> <p>If the required size is not listed in the <b>Size</b> box, click <b>Add Custom</b>. When the Custom Page Size window appears, set the paper size and click <b>Ok</b>. The size setting appears in the Size list so that you can select it.</p> <div data-bbox="651 1400 953 1758"> </div> <p>Enter the custom name you want to use.</p> <p>Enter the paper size.</p> |

| Property        | Description   |
|-----------------|---|
| ③ <b>Source</b> | <p>Make sure that <b>Source</b> is set to the corresponding paper tray.</p> <p>The <b>Manual Feed</b> source is used when printing to special materials. You need to load one sheet at a time into the Bypass Tray. See page 3.8.</p> <p>If the paper source is set to <b>Auto Select</b>, the machine automatically picks up print materials according to the following order: the Bypass tray and the paper tray.</p> |
| ④ <b>Type</b>   | <p>Make sure that <b>Type</b> is set to <b>Printer Default</b>. If you load a different type of print material, select the corresponding paper type. For more information on print materials, refer to Chapter 3, "Paper Handling."</p>   |


## Printing Multiple Pages on One Sheet of Paper (N-Up Printing)




You can select the number of pages to print on a single sheet of paper. To print more than one page per sheet, the pages will appear decreased in size and arranged on the sheet. You can print up to 16 pages on one sheet.

- 1 To change the print settings from your software application, access the printer properties. See page 5.2.
- 2 From the **Layout** tab, choose **Multiple Pages per Side** in the **Type** drop-down list.

- 3 Select the number of pages you want to print per sheet (1, 2, 4, 9 or 16) in the **Pages per Side** drop-down list.




- 4 Select the page order in the **Page Order** drop-down list, if necessary.



Check **Print Page Border** to print a border around each page on the sheet. **Print Page Border** is enabled only, if the pages per sheet is 2, 4, 9 or 16.

- 5 Click the **Paper** tab and select the paper source, size and type.
- 6 Click **OK** and print the document.


## Printing a Reduced or Enlarged Document



You can scale your print job on a page.


- 1 When you change the print settings from your software application, access the printer properties. See page 5.2.
- 2 From the **Layout** tab, select **Reduce/Enlarge** in the **Type** drop-down list.
- 3 Enter the desired scaling rate in the **Percentage** input box.

You can also click the ▲ or ▼ button.




- 4 Click the **Paper** tab and select the paper source, size and type.
- 5 Click **OK** and print the document.

## Fitting Your Document to a Selected Paper Size




You can scale your print job to any selected paper size regardless of the digital document size. This can be useful when you want to check fine details on a small document.

- 1 When you change the print settings from your software application, access the printer properties. See page 5.2.
- 2 From the **Layout** tab, select **Fit to Page** in the **Type** drop-down list.
- 3 Select the correct size from the **Target Paper** drop-down list.




- 4 Click the **Paper** tab and select the paper source, size and type.
- 5 Click **OK** and print the document.

## Printing Posters





You can print a single-page document onto 4, 9 or 16 sheets of paper, for the purpose of pasting the sheets together to form one poster-size document.

- 1 When you change the print settings from your software application, access the printer properties. See page 5.2.
- 2 From the **Layout** tab, select **Poster** in the **Type** drop-down list.




- 3 Configure the poster option:

You can select the page layout from 2x2, 3x3 or 4x4. If you select 2x2, the output will be automatically stretched to cover 4 physical pages.



Specify an overlap in millimeters or inches to make it easier to reconstruct the resulting poster.



- 4 Click the **Paper** tab and select the paper source, size and type.
- 5 Click **OK** and print the document. You can complete the poster by reconstructing the results.

## Using Watermarks




The Watermark option allows you to print text over an existing document. For example, you may want to have large gray letters reading "DRAFT" or "CONFIDENTIAL" printed diagonally across the first page or all pages of a document.

There are several predefined watermarks that come with your machine, and they can be modified or you can add new ones to the list.

5

## Using an Existing Watermark

- 1 When you change the print settings from your software application, access the printer properties. See page 5.2.
- 2 Click the **Extras** tab and select a watermark in the **Watermark** drop-down list. You will see the selected watermark in the preview image.






- 3 Click **Ok** and start printing.

## Creating a Watermark

- 1 When you change the print settings from your software application, access the printer properties. See page 5.2.
- 2 Click the **Extras** tab and click the **Edit** button in the **Watermark** section. The Edit Watermarks window appears.



- 3 Enter the text message you want to print in the **Watermark Message** box.

The message will be displayed in the preview window. The preview image is provided so that you can see how the watermark will appear on the printed page.

If the **First Page Only** box is checked, the watermark will be printed on the first page only.

- 4 Select the desired watermark options.

You can select the font name, style and size and grayscale level from the **Font Attributes** section and set the angle of the watermark from the **Message Angle** section.

- 5 Click **Add** to add a new watermark to the list.
- 6 When you finish creating, click **Ok** and start printing.

To stop printing the watermark, select **<No Watermark>** in the **Watermark** drop-down list.

## Editing a Watermark

- 1 When you change the print settings from your software application, access the printer properties. See page 5.2.
- 2 Click the **Extras** tab and click the **Edit** button in the **Watermark** section. The Edit Watermarks window appears.
- 3 Select the watermark you want to edit in the **Current Watermarks** list, and change the watermark message and the options. Refer to "Creating a Watermark" on page 5.14.
- 4 Click **Update** to save the changes.
- 5 Click **Ok**.

## Deleting a Watermark

- 1 When you change the print settings from your software application, access the printer properties. See page 5.2.
- 2 From the **Extras** tab, click the **Edit** button in the **Watermark** section. The Edit Watermarks window appears.
- 3 Select the watermark you want to delete in the **Current Watermarks** list and click **Delete**.
- 4 Click **Ok**.

---


# Using Overlays

## What is an Overlay?



An overlay is text and/or images stored in the computer hard disk drive (HDD) as a special file format that can be printed on any document. Overlays are often used to take the place of preprinted forms and letterhead paper. Rather than using preprinted letterhead, you can create an overlay containing the exact same information that is currently on your letterhead. To print a letter with your company's letterhead, you do not need to load preprinted letterhead paper in the machine. You need only tell the machine to print the letterhead overlay on your document.

## Creating a New Page Overlay




To use a page overlay, you must create a new page overlay containing your logo or image.


- 1 Create or open a document containing text or an image for use in a new page overlay. Position the items exactly as you wish them to appear when printed as an overlay. If needed, save the file for later use.
- 2 When you change the print settings from your software application, access the printer properties. See page 5.2.
- 3 Click the **Extras** tab and click **Edit** button in the **Overlay** section.



- 4 In the Edit Overlays window, click **Create Overlay**.



- 5 In the Create Overlay window, type a name of up to eight characters in the **File name** box. Select the destination path, if necessary. (The default is C:\Formover).



5

- 6 Click **Save**. You can see the name in **Overlay List**.

- 7 Click **OK** or **Yes** until you complete creating.

The file is not printed out. Instead it will be stored on your computer HDD disk.




**NOTE:** The overlay document size must be the same as documents you will print with the overlay. Do not create an overlay with a watermark.

## Using a Page Overlay


After an overlay has been created, it is ready to be printed with your document. To print an overlay with a document:

- 1 Create or open the document you want to print.
- 2 When you change the print settings from your software application, access the printer properties. See page 5.2.
- 3 Click the **Extras** tab.
- 4 Select the overlay you want to print from the **Overlay** drop-down list box.
- 5 If the desired overlay file does not appear in the **Overlay** list, click the **Edit** button and **Load Overlay**, and select the overlay file.



If you have stored the overlay file you want to use into an external source, you can also load the file when you access this Load Overlay window.

After you select the file, click **Open**. The file is now shown in the **Overlay List** box and is available for printing. Select the overlay from the **Overlay List** box.



- 6 If necessary, click **Confirm Page Overlay When Printing**. If this box is checked, a message window will appear each time you submit a document for printing, asking you to confirm your wish to print an overlay on your document.

Answering **Yes** to the window means that the selected overlay will be printed with your document. Answering **No** to the window cancels overlay printing.

If this box is empty and an overlay has been selected, the overlay will be automatically printed with your document.

- 7 Click **OK** or **Yes** until the printing starts.

The selected overlay will be downloaded with your print job and printed on your document.



---

**Note:** The resolution of the overlay document must be the same as that of the document you will print with the overlay.

---

## Deleting a Page Overlay

You can delete page overlays that are no longer used.

- 1 In the printer properties window, click the **Extras** tab.
- 2 Click **Edit** in the **Overlay** section.
- 3 Select the overlay you want to delete from the **Overlay List** box.
- 4 Click **Delete Overlay**.
- 5 Click **OK** until you exit the Print window.


## Setting Graphic Properties

Use the following graphic options to adjust the print quality for your specific printing needs. See page 5.2 for more information about accessing printer properties.

Click the **Graphics** tab to display the properties shown below.



| Property            | Description   |
|---------------------|---|
| <b>1 Resolution</b> | You can select the printing resolution by choosing from <b>600 dpi (Normal)</b> or <b>300 dpi (Draft)</b> . The higher the setting, the sharper the clarity of printed characters and graphics. Higher settings may increase time it takes to print a document.   |
| <b>2 Toner Save</b> | Selecting this option will extend the life of your toner cartridge and reduce your cost per page without a significant reduction in the print quality. <ul style="list-style-type: none"><li>• <b>Printer Setting:</b> If you select this option, the Toner Save feature is determined by the setting you've made on the control panel of the printer.</li><li>• <b>On:</b> Select this option to allow the printer to use less toner on each page.</li><li>• <b>Off:</b> If you do not need to save toner to print a document, select this option.</li></ul> |

| Property                         | Description   |
|----------------------------------|---|
| <p><b>3 Advanced Options</b></p> | <p>You can set advanced settings by clicking the <b>Advanced Options</b> button.</p>  <p><b>Darkness</b></p> <p>Use this option to lighten or darken the image appearance in your print.</p> <ul style="list-style-type: none"> <li>• <b>Normal:</b> This setting is for normal documents.</li> <li>• <b>Light:</b> This setting is for bolder line widths or darker gray-scale images.</li> <li>• <b>Dark:</b> This setting is for finer line width, higher definition in graphics and lighter gray-scale images.</li> </ul> <p>When the <b>Darken Text</b> option is checked, all text in your document is allowed to print darker than a normal document.</p> <p><b>Print All Text Black</b></p> <p>When the <b>Print All Text Black</b> option is checked, all text in your document is allowed to print solid black, regardless of the color it appears on the screen. When it is not checked, colored text is allowed to print in shades of gray.</p> |



| Property                                 | Description   |
|--|---|
| <b>3 Advanced Options</b><br>(continued) | <div> <b>True Type Options</b><br/> This option determines what the driver tells the machine about how to image the text in your document. Select the appropriate setting according to the status of your document. </div> <ul style="list-style-type: none"> <li> <b>Download as Bit Image:</b> When this option is selected, the driver will download the font data as bitmap images. Documents with complicated fonts, such as Korean or Chinese, or various types of fonts will print faster in this setting. </li> <li> <b>Print as Graphics:</b> When this option is selected, the driver will download any fonts as graphics. When printing documents with high graphic content and relatively few TrueType fonts, printing performance (speed) may be enhanced in this setting. </li> </ul> |

---

## Setting Up the Locally Shared Printer

You can connect the machine directly to a selected computer, which is called "host computer," on the network. Your machine can be shared by other users on the network through a Windows 9x, Me, 2000, XP or NT 4.0 network printer connection.

### In Windows 9x/Me

#### Setting Up the Host Computer

- 1 Start Windows.
- 2 From the **Start** menu, select **Control Panel** and double-click on the **Network** icon.
- 3 Check the **File and Print Sharing** box and click **OK**.

- 4 Click **Start** and select **Printers** from **Settings**. Double-click your printer name.
- 5 Select **Properties** in the **Printer** menu.
- 6 Click the **Sharing** tab and check the **Shared As** box. Fill in the **Shared Name** field and then click **OK**.

## Setting Up the Client Computer

- 1 Right-click **Start** and select **Explorer**.
- 2 Open your network folder in the left column.
- 3 Right-click the shared name and select **Capture Printer Port**.
- 4 Select the port you want, check the **Reconnect at log on** box and then click **OK**.
- 5 From the **Start** menu, select **Settings** and then **Printers**.
- 6 Double-click your printer icon.
- 7 From the **Printer** menu, select **Properties**.
- 8 From the **Details** tab, select the printer port and click **OK**.

## In Windows NT 4.0/2000/XP

### Setting Up the Host Computer

- 1 Start Windows.
- 2 For Windows NT 4.0/2000, from the **Start** menu, select **Settings** and then **Printers**.  
  
For Windows XP, from the **Start** menu, select **Printers and Faxes**.
- 3 Double-click your printer icon.
- 4 From the **Printer** menu, select **Sharing**.

- 5** For Windows NT 4.0, check the **Shared** box.  
For Windows 2000, check the **Shared As** box.  
For Windows XP, check the **Share this printer** box.
- 6** For Windows NT 4.0, fill in the **Share Name** field and click **OK**.  
For Windows 2000/XP, fill in the **Shared Name** field and click **OK**.

## Setting Up the Client Computer

- 1** Right-click **Start** and select **Explorer**.
- 2** Open your network folder in the left column.
- 3** Click the shared name.
- 4** For Windows NT 4.0/2000, from the **Start** menu, select **Settings** and **Printers**.  
For Windows XP, from the **Start** menu, select **Printers and Faxes**.
- 5** Double-click your printer icon.
- 6** From the **Printer** menu, select **Properties**.
- 7** Press the **Ports** tab and click **Add Port**.
- 8** Select **Local Port** and click **New Port**.
- 9** Fill in the **Enter a port name** field and enter the shared name.
- 10** Click **OK** and click **Close**.
- 11** For Windows NT 4.0, click **OK**.  
For Windows 2000/XP, click **Apply** and click **OK**.



# 6

## SCANNING

Scanning with your machine lets you turn pictures and text into digital files on your computer. Then you can fax or e-mail the files, display them on your web site or use them to create projects that you can print out using Samsung SmarThru software.

This chapter includes:

- **Scanning Basics**
- **Scanning Using the Samsung SmarThru**
- **Scanning Process with TWAIN-enabled Software**

---

## Scanning Basics

Your machine offers two ways to begin scanning:

- From the Samsung SmarThru software: Launch Samsung SmarThru and open the Scan Wizard to begin scanning. See below.
- From TWAIN-compliant software: You can use other software including Adobe PhotoDeluxe and Adobe Photoshop. See page 6.5.



---

### NOTES:

- To scan with your machine, you must install the MFP driver.
  - Scanning is done through the same LPT or USB port currently assigned for your printer port.
- 

---

## Scanning Using the Samsung SmarThru

Samsung SmarThru is the accompanying software for your machine. With the SmarThru, scanning becomes a pleasure.


Follow these steps to start scanning using the SmarThru:

- 1** Make sure that your machine and computer are turned on and properly connected to each other.
- 2** Place a single document **face down** on the document glass then close the cover. For further details, see page 4.2.


OR

Load the document(s) to be scanned **face up** into the ADF (Automatic Document Feeder). For further details, see page 4.4.

- 3 Once you have installed Samsung software, you see the SmarThru icon on the desktop window. Double-click the **SmarThru 3** icon.



The SmarThru 3 window opens.



- 4 To open the Scan Wizard, click the **Scan Wizard** icon in the plugin bar on the left of the SmarThru 3 window.



The Scan Wizard lets you use the following services:

- **Scan**

Lets you scan the original documents and save them in the Image Manager of the Samsung SmarThru system. The Image Manager is an image database manager and image editor program.

- **Copy**

Lets you use your machine to produce professional quality copies. You can adjust the image size and select advanced settings.

- **Scan to Email**

Lets you scan the original documents and then launches a default mail program of your system, such as Microsoft Outlook Express, so that you can send the scanned image attached to a new mail. To send e-mail using the Samsung SmarThru system, you need to enable the Internet Gate and configure an e-mail account in SmarThru Configuration. Refer to the SmarThru User's Guide.

- **Scan to FAX**

Lets you scan the original documents and then launches a New Fax form which helps you to send them as a fax image. This service is available only when you enable and configure the Fax Gate in SmarThru Configuration. Refer to the SmarThru User's Guide.

- **Scan to WEB**


Lets you scan the original documents for further publishing to the Web.

- **Scan to OCR**

Lets you scan the original documents and pass them to the OCR program. OCR (Optical Character Recognition) is the process of converting a scanned image into text that you can edit in a word processing program. After you scan your document, the software processes or "recognizes" it. Then you can change it and either save the file or open it in any word processing program on your computer.

**5** Click the desired service icon.

- 6 The Samsung Scan Manager opens for the selected service. Adjust the scan settings. You can use the **Help** button to receive on-line help.



- 7 To start scanning, click **Scan**.

For more information, please refer to the SmarThru User's Guide which came with your machine.



**NOTE:** If you want to cancel the scan job, press the **Stop/Clear** button on the control panel.

## Scanning Process with TWAIN-enabled Software

6

If you want to scan documents using other software, you will need to use TWAIN-compliant software, such as Adobe PhotoDeluxe or Adobe Photoshop. The first time you scan with your machine, select it as your TWAIN source in the application you use.

The basic scanning process involves a number of steps:

- Place your photograph or page on the document glass.
- Open an application, such as PhotoDeluxe or Photoshop.
- Open the TWAIN window and set the scan options.
- Scan and save your scanned image.

You need to follow the program's instructions for acquiring an image. Please refer to the application's User's Guide.



# *MEMO*



# 7

## MAINTENANCE

This chapter provides information for maintaining the toner cartridge and your machine.

This chapter includes:

- **Clearing the Memory**
- **Cleaning Your Machine**
- **Maintaining the Toner Cartridge**
- **Consumables and Replacement Parts**

---

## Clearing the Memory

You can selectively clear information stored in your machine's memory.

- 1 Press **Menu** on the control panel until "Maintenance" appears on the top line of the display.
- 2 Press the scroll button (◀ or ▶) until you see "Clear Memory" on the bottom line and press **Enter**.

The first available menu item, "Paper Setting," displays on the bottom line.

- 3 Press the scroll button (◀ or ▶) until you see the item you want to clear.
  - Paper Setting: Restores all of the Paper Setting options to the factory default.
  - Copy Setup: Restores all of the Copy Setup options to the factory default.
  - Fax Setup: (only for SCX-4216F) Restores all of the Fax Setup options to the factory default.
  - Fax Feature: (only for SCX-4216F) All of the scheduled fax jobs in the machine's memory are canceled.
  - Advanced Fax: (only for SCX-4216F) Restores all of the Advanced Fax setting options to the factory default.
  - **Send Report**: (only for SCX-4216F) Clears all of records of your faxes sent.
  - **RCV Report**: (only for SCX-4216F) Clears all of records of your faxes received.
  - Phone Book: (only for SCX-4216F) Clears the speed dial or group dial numbers stored in the memory.
- 4 Press **Enter**. The selected memory is cleared and the display asks you to continue clearing the next item.
- 5 Repeat steps 2 and 3 to clear another item.

OR

To return to Standby mode, press **Stop/Clear**.

---

# Cleaning Your Machine

To maintain the print quality, follow the cleaning procedures below each time the toner cartridge is replaced or if print quality problems occur.



## CAUTIONS:

- Do not pour or spray water directly onto any part of your machine.
- Do not use ammonia-based cleaners or volatile solvents, such as thinner, on or around the machine. These can damage the machine.
- While cleaning the inside of the machine, be careful not to touch the transfer roller, which is located underneath the toner cartridge. Oil from your fingers can cause print quality problems.


## Cleaning the Outside

Wipe the outside surface of the machine with a soft, clean and lint-free cloth. You can dampen the cloth slightly with water, but be careful not to let any water drip onto the machine or the inside of it.

## Cleaning the Inside

During the printing process, paper, toner and dust particles can accumulate inside the machine. This buildup can cause print quality problems, such as toner specks or smearing. Cleaning the inside of the machine will clear or reduce these problems.

- 1 Turn the machine off and unplug the power cord. Wait for the machine to cool down.
- 2 Open the front cover and pull the toner cartridge out, lightly pushing it down.



- 3 With a dry and lint-free cloth, wipe away any dust and spilled toner from the toner cartridge area and the toner cartridge cavity.



**CAUTION:** To prevent damage to the toner cartridge, do not expose it to light for more than a few minute. Cover it with a piece of paper, if necessary. Do not touch the black transfer roller inside the machine.


- 4 Reinsert the toner cartridge and close the cover.
- 5 Plug in the power cord and turn the machine on.

## Cleaning the Scan Unit

Keeping the scan unit clean helps ensure the best possible copies. We suggest that you clean the scan unit at the start of each day and during the day, as needed.

- 1 Slightly dampen a soft lint-free cloth or paper towel with water.
- 2 Open the document cover.

- 3 Wipe the surface of the document glass and ADF glass (for SCX-4116/4216F) until it is clean and dry.



- 4 Wipe the underside of the white document cover and white sheet (for SCX-4116/4216F) until it is clean and dry.
- 5 Close the document cover.

---

## Maintaining the Toner Cartridge

### Toner cartridge storage

To get the most from the toner cartridge, keep the following guidelines in mind:

- Do not remove the toner cartridge from its package until ready for use.
- Do not refill the toner cartridge. **The machine warranty does not cover damage caused by using a refilled cartridge.**
- Store toner cartridges in the same environment as your machine.
- To prevent damage to the toner cartridge, do not expose it to light for more than a few minute.

## Saving toner

To save toner, press the **Toner Save** button on the printer control panel; see page 1.19. The button backlight will be lit. Using this feature will extend the life of the toner cartridge and reduce your cost per page, but it will reduce the print quality.


## Expected Cartridge Life

The life of the toner cartridge depends on the amount of toner that print jobs require. When printing text at 5% coverage, a new toner cartridge lasts an average of 3,000 pages. (The original toner cartridge supplied with the printer lasts an average of 1,000 pages.) The actual number may vary according to the print density of the page you print. If you print a lot of graphics, you may need to change the cartridge more often.


## Redistributing Toner

When the toner cartridge is near the end of its life, white streaks or light print will occur. The LCD displays the warning message "Toner Low." You can temporarily reestablish the print quality by redistributing the remaining toner in the cartridge.

- 1 Open the front cover.



- 2 Pull the toner cartridge out and gently shake the cartridge to distribute the toner evenly inside the cartridge.







**NOTE:** If the toner gets on your clothing, wipe it off with a dry cloth and wash clothing in cold water. Hot water sets the toner into fabric.

- 3 Reinstall the cartridge and close the front cover.


## Replacing the Toner Cartridge

If the toner eventually runs out, only blank pages will print when a print job is sent or when a fax is received. At this stage, the toner cartridge needs to be replaced. The display shows the warning message, "Toner Empty" and the  indicator on the control panel turns on.

- 1 Open the front cover.



- 2 Lightly pushing the the used cartridge down, pull it out.









**NOTE:** Help the environment by recycling your used toner cartridge. Refer to the recycling brochure packed with the toner cartridge for details.

- 3 Unpack the new toner cartridge and gently shake it horizontally four or five times to distribute the toner evenly inside the cartridge.




Save the box and the cover for shipping.

- 4 Slide the new toner cartridge in until it locks into place.



- 5 Close the front cover.



## Setting the Notify Toner Option

(For SCX-4216F)

If you have set the Notify Toner menu option to "On", your machine automatically sends a fax to your service company or the dealer to notify them that your machine requires a new toner cartridge when the toner cartridge needs to be replaced.

- 1 Press **Menu** on the control panel until "Maintenance" appears on the top line of the display. The first available menu item, "Clean Drum," displays on the bottom line.
- 2 Press the scroll button (◀ or ▶) to display "Notify Toner" on the bottom line and press **Enter**.
- 3 Press the scroll button (◀ or ▶) to change the setting.  
  
Select "On" to enable this feature. Selecting "Off" disables this feature.
- 4 Press **Enter** to save the selection.

## Cleaning the Drum

If there are streaks or spots on your print, the OPC drum of the cartridge may require cleaning.

- 1 Before setting the cleaning procedure, make sure that paper is loaded in the machine.
- 2 Press **Menu** on the control panel until "Maintenance" appears on the top line of the display. The first available menu item, "Clean Drum," displays on the bottom line.
- 3 Press **Enter**.  
  
The display confirms your selection.
- 4 Press **Enter** to accept "Yes."  
  
The machine prints out a cleaning page. Toner particles on the drum surface are affixed to the paper.
- 5 If the problem remains, repeat steps 1 through 4.

---

## Consumables and Replacement Parts

From time to time, you will need to replace the toner cartridge, roller, and fuser unit to maintain top performance and to avoid print quality problems and paper feed problems resulting from worn parts.

The following items should be replaced after you have printed a specified number of pages. See the table below.

| Items                | Yield (Average) |
|----------------------|-----------------|
| ADF rubber pad       | 20,000          |
| ADF roller           | 50,000          |
| Paper feeding roller | 60,000          |
| Transfer roller      | 60,000          |
| Fuser unit           | 60,000          |

To purchase the consumables and replacement parts, contact your Samsung dealer or the retailer where you bought your machine. We strongly recommend that items be installed by a trained service professional, except for the toner cartridge.



# 8

## TROUBLESHOOTING

This chapter gives helpful information for what to do if you encounter an error.

This chapter includes:

- **Clearing Document Jams (For SCX-4116/4216F)**
- **Clearing Paper Jams**
- **Clearing LCD Error Messages**
- **Solving Problems**

---

## Clearing Document Jams (For SCX-4116/4216F)


If a document jams while it is feeding through the ADF (Automatic Document Feeder), "Document Jam" appears on the display.

### Input Misfeed

- 1 Remove the remaining documents from the ADF.
- 2 Open the ADF top cover.



- 3 Push the bushing on the one end of the ADF roller in the direction of the arrow (a) and rotate it in the direction of the arrow (b). Then remove the roller from the slot and pull the document gently to the right and out of the ADF.




- 4 Close the ADF top cover. Then load the documents back into the ADF.



**NOTE:** To prevent document jams, use the document glass for thick, thin or mixed documents.

## Exit Misfeed


- 1 Remove the remaining documents from the ADF.
- 2 Open the document cover and turn the release knob to remove the misfed documents from the document output tray.



- 3 Close the document cover. Then load the documents back into the ADF.

## Roller Misfeed

- 1 Remove the remaining documents from the ADF.
- 2 Open the document cover.
- 3 Turn the release knob so that you can easily seize the misfed document, and remove the document from the roller or the feed area by carefully pulling it to the right by using both hands.



- 4 Close the document cover. Then load the documents back into the ADF.

---

## Clearing Paper Jams

If paper jams occur, "Paper Jam" appears on the display. Refer to the table below to locate and clear the paper jam.

| Message     | Location of Jam                                 | Go to    |
|-------------|---|----------|
| Paper Jam 0 | In the paper feed area                          | below    |
| Paper Jam 1 | In the paper exit area                          | page 8.5 |
| Paper Jam 2 | In the fuser area or around the toner cartridge | page 8.7 |
| Bypass Jam  | In the Bypass tray                              | page 8.8 |


To avoid tearing the paper, pull the jammed paper out gently and slowly. Follow the steps below to clear a jam.

### In the Paper Feed Area


- 1 Open and close the front cover. The jammed paper automatically exits the machine.

If the paper does not exit, continue to Step 2.

- 2 Pull the paper tray open.




- 3 Remove the jammed paper by gently pulling it straight out.



If there is any resistance and the paper does not move when you pull or if you cannot see the paper in this area, skip to the fuser area around the toner cartridge; see page 8.7.

- 4 Insert the paper tray into the machine until it snaps into place.



- 5 Open and close the front cover to resume printing.


## In the Paper Exit Area

- 1 Open and close the front cover. The jammed paper automatically exits the machine.


If the paper does not exit, continue to Step 2.




- 2** Gently pull the paper out of the front output tray. Skip to Step 6.



- 3** If there is any resistance and the paper does not move when you pull or if you cannot see the paper in the front output tray, open the rear cover.



- 4** Remove the jammed paper by gently pulling it straight out.




- 5 Close the rear cover.
- 6 Open and close the front cover to resume printing.

## In the Fuser Area or Around the Toner Cartridge




**NOTE:** The fuser area is hot. Take care when removing paper from the machine.


- 1 Open the front cover and pull the toner cartridge out, lightly pushing it down.



- 2 Remove the jammed paper by gently pulling it straight out.




- 3 Replace the toner cartridge and close the front cover. Printing automatically resumes.



## In the Bypass Tray

"Bypass Jam" appears on the display when you try to print using the Bypass tray and when the machine does not detect paper due to no paper or improper paper loading.

"Bypass Jam" also may occur when the paper is not properly fed into the machine through the Bypass tray. In that case, pull the paper out of the machine.



## Tips for Avoiding Paper Jams

By selecting the correct paper types, most paper jams can be avoided. If a paper jam occurs, follow the steps outlined in "Clearing Paper Jams" on page 8.4.

- Follow the procedures in "Loading Paper" on page 1.12. Ensure that the adjustable guides are positioned correctly.
- Do not overload the paper tray. Ensure that the paper is below the paper capacity mark on the inside wall of the paper tray.
- Do not remove the paper from the tray while your machine is printing.
- Flex, fan and straighten the paper before loading.
- Do not use creased, damp or highly curled paper.
- Do not mix paper types in the paper tray.
- Use only recommended print materials. See "Paper Specifications" on page B.6.
- Ensure that the recommended print side of print materials is facing down in the paper tray and facing up in the Bypass tray.

## Clearing LCD Error Messages

| Display                                       | Meaning   | Suggested solutions   |
|---|---|---|
| Bypass Jam                                    | Your machine detects non feeding from the Bypass tray.  | Load paper in the Bypass tray. Or remove the jammed paper from the Bypass tray.   |
| Cancel ?<br>1:Yes 2:No                        | Your machine's memory is full during the machine stores the document into the memory.   | To cancel the fax job, press the <b>1</b> button to accept "Yes."<br>If you want to send the pages were stored, press the <b>2</b> button to accept "No." You should send the remaining pages later when the memory is available. |
| Comm. Error<br>(only for SCX-4216F)           | The machine has a communication problem.  | Ask the sender to try again.  |
| Document Jam<br>(only for SCX-4116/<br>4216F) | The loaded document has jammed in the ADF (Automatic Document Feeder).  | Clear the document jam. See page 8.2.   |
| Door Open                                     | The front or rear cover is not securely latched.  | Close the cover until it locks in place.  |
| CRU Fuser Error                               | There is a problem in the fuser unit.   | Unplug the power cord and plug it back in. If the problem persists, please call for service.  |
| Heating Error                                 |   |   |
| Open Heat Error                               |   |   |
| Over Heat                                     |   |   |
| Group Not Available<br>(only for SCX-4216F)   | You have tried to select a group location number where only a single location number can be used, such as when adding locations for a broadcasting operation. | Just use a speed dial number or dial a number manually using the number keypad.   |

| Display                                  | Meaning   | Suggested solutions   |
|--|---|---|
| Incompatible<br>(only for SCX-4216F)     | <p>The remote machine did not have the requested feature, such as a delayed transmission.</p> <p>It also occurs if the remote machine does not have enough memory space to complete the operation you are attempting.</p> | Reconfirm the remote machine's features.  |
| Invalid Cartridge                        | You have used unauthorized cartridge.   | You must use a Samsung approved cartridge.  |
| Line Busy<br>(only for SCX-4216F)        | The remote party did not answer or the line is already engaged.   | Try again after a few minutes.  |
| Line Error<br>(only for SCX-4216F)       | Your machine cannot connect with the remote machine or has lost contact because of a problem with the phone line.   | <p>Try again. If the problem persists, wait an hour or so for the line to clear and try again.</p> <p>Or, turn the ECM mode on. See the Facsimile User's Guide.</p> |
| Load Document                            | You have attempted to set up a copy or fax operation with no document loaded.   | Load a document and try again.  |
| LSU Error                                | A problem has occurred in the LSU (Laser Scanning Unit).  | Unplug the power cord and plug it back in. If the problem persists, please call for service.  |
| Memory Full<br>(only for SCX-4216F)      | The memory is full.   | Delete unnecessary documents, retransmit after more memory becomes available or split the transmission into more than one operation.                                |
| No Answer<br>(only for SCX-4216F)        | The remote fax machine has not answered after several redial attempts.  | Try again. Make sure that the remote machine is operational.  |
| No Cartridge                             | The toner cartridge is not installed.   | Install the toner cartridge. See page 1.10.   |
| No. Not Assigned<br>(only for SCX-4216F) | The speed dial location you tried to use has no number assigned to it.  | Dial the number manually using the number keypad or assign the number. <b>See the Facsimile User's Guide.</b>   |

| Display  | Meaning   | Suggested solutions   |
|--|---|---|
| No Paper                                       | The paper in the paper tray has run out.  | Load paper in the paper tray. See page 1.12.  |
| Operation Not Assigned<br>(only for SCX-4216F) | You are doing in the Add/Cancel operation, but there is no jobs waiting.                  | Check the display to see if there is any scheduled job. The display should indicate them in Standby mode, for example, <b>Delay Fax</b> . |
| Paper Jam 0                                    | Paper has jammed in the feeding area of the paper tray.                                   | Clear the jam. See page 8.4.  |
| Paper Jam 1                                    | Paper has jammed in the paper exit area.  | Clear the jam. See page 8.5.  |
| Paper Jam 2                                    | Paper has jammed in the fuser area.   | Clear the jam. See page 8.7.  |
| Power Failure                                  | Power has turned off then on and the machine's memory has not been saved.                 | You need to start again the job which you were trying to do before the power failure.   |
| Retry Redial?<br>(only for SCX-4216F)          | The machine is waiting for a specified time interval to redial a previously busy station. | You can press <b>Enter</b> to immediately redial, or <b>Stop/Clear</b> to cancel the redial operation.                                    |
| Stop Pressed                                   | The <b>Stop/Clear</b> button is pressed during a copy or fax operation.                   | Try again.  |
| Toner Empty                                    | The toner cartridge has run out. The machine stops.                                       | Replace with a new toner cartridge. See page 7.7.   |
| Toner Low                                      | The toner is almost empty.  | Take out the toner cartridge and gently shake it. By doing this, you can temporarily reestablish printing operations.                     |

## Solving Problems

The following chart lists some conditions that may occur and the recommended solutions. Follow the suggested solutions until the problem is corrected. If the problem persists, please call for service.

### Paper Feeding Problems

| Condition  | Suggested solutions  |
|--|--|
| Paper is jammed during printing.                 | Clear the paper jam. See page 8.4.   |
| Paper sticks together.                           | <ul style="list-style-type: none"><li>• Ensure that there is not too much paper in the paper tray. The paper tray can hold up to 250 sheets of paper, depending on the thickness of your paper.</li><li>• Make sure that you are using the correct type of paper. See "Paper Specifications" on page B.6.</li><li>• Remove paper from the paper tray and flex or fan the paper.</li><li>• Humid conditions may cause some paper to stick together.</li></ul>   |
| Multiple sheets of paper do not feed.            | <ul style="list-style-type: none"><li>• Different types of paper may be stacked in the paper tray. Load the paper of only one type, size and weight.</li><li>• If multiple sheets have caused a paper jam, clear the paper jam. See page 8.4.</li></ul>  |
| Paper does not feed into the machine.            | <ul style="list-style-type: none"><li>• Remove any obstructions inside the machine.</li><li>• Paper has not been loaded correctly. Remove paper from the tray and reload it correctly.</li><li>• There is too much paper in the paper tray. Remove excess paper from the tray.</li><li>• The paper is too thick. Use only paper that meets the specifications required by the machine. See "Paper Specifications" on page B.6.</li></ul>                       |
| The paper keeps jamming.                         | <ul style="list-style-type: none"><li>• There is too much paper in the paper tray. Remove excess paper from the tray. If you are printing on special materials, use the Bypass tray.</li><li>• An incorrect type of paper is being used. Use only paper that meets the specifications required by the machine. See "Paper Specifications" on page B.6.</li><li>• There may be debris inside the machine. Open the front cover and remove the debris.</li></ul> |
| Transparencies stick together in the paper exit. | Use only the transparencies specifically designed for a laser printer. Remove each transparency as it exits from the machine.  |



| Condition                                 | Suggested solutions   |
|---|---|
| Envelopes skew or fail to feed correctly. | Ensure that the paper guide is against both sides of the envelopes. |

## Printing Problems




| Condition                   | Possible cause   | Suggested solutions  |
|-----------------------------|--|--|
| The machine does not print. | The machine is not receiving power.  | Check the power cord connections. Check the power switch and the power source.   |
|                             | The machine is not selected as the default printer.                                  | Select <b>Samsung SCX-4x16 Series</b> as your default printer in your Windows.   |
|                             | Check the machine for the following:   | <ul style="list-style-type: none"> <li>• The front or rear cover is not closed.</li> <li>• Paper is jammed.</li> <li>• No paper is loaded.</li> <li>• The toner cartridge is not installed.</li> </ul> <p>If a printer system error occurs, contact your service representative.</p> |
|                             | The connection cable between the computer and the machine is not connected properly. | Disconnect the printer cable and reconnect it.   |
|                             | The connection cable between the computer and the machine is defective.              | If possible, attach the cable to another computer that is working properly and print a job. You can also try using a different printer cable.  |
|                             | The port setting is incorrect.   | Check the Windows printer setting to make sure that the print job is sent to the correct port, for example, LPT1. If the computer has more than one port, make sure that the machine is attached to the correct one.   |
|                             | The machine may be configured incorrectly.   | Check the printer properties to ensure that all of the print settings are correct.   |
|                             | The printer driver may be incorrectly installed.                                     | <b>Remove the printer driver and then reinstall it; see page 2.9 and page 2.4 respectively.</b>  |
|                             | The machine is malfunctioning.   | Check the display message on the control panel to see if the machine is indicating a system error.   |





| Condition  | Possible cause   | Suggested solutions  |
|--|--|--|
| The machine selects print materials from the wrong paper source.   | The paper source selection in the printer properties may be incorrect.       | For many software applications, the paper source selection is found under the <b>Paper</b> tab within the printer properties. Select the correct paper source. See page 5.8.   |
| Print job is extremely slow.                                       | The job may be very complex.   | Reduce the complexity of the page or try adjusting the print quality settings.<br><br>The maximum print speed of your machine is 17 PPM for Letter-sized paper.  |
|  | If you are using Windows 9x/Me, the Spooling Setting may be set incorrectly. | From the <b>Start</b> menu, choose <b>Settings</b> and <b>Printers</b> . Right-click the <b>Samsung SCX-4x16 Series</b> printer icon, choose <b>Properties</b> , click the <b>Details</b> tab, and then choose the <b>Spool Settings</b> button. Select the desired spool setting. |
| Half the page is blank.  | The page orientation setting may be incorrect.                               | Change the page orientation in your application. See page 5.3.   |
|  | The paper size and the paper size settings do not match.                     | Ensure that the paper size in the printer driver settings matches the paper in the tray.   |
| The machine prints, but the text is wrong, garbled, or incomplete. | The printer cable is loose or defective.                                     | Disconnect the printer cable and reconnect. Try a print job that you have already printed successfully. If possible, attach the cable and the machine to another computer and try a print job that you know works. Finally, try a new printer cable.                               |
|  | The wrong printer driver was selected.                                       | Check the application's printer selection menu to ensure that your machine is selected.  |
|  | The software application is malfunctioning.                                  | Try printing a job from another application.   |
|  | The operating system is malfunctioning.                                      | Exit Windows and reboot the computer. Turn the machine off and then back on again.   |





| Condition   | Possible cause   | Suggested solutions  |
|---|--|--|
| Pages print, but are blank.   | The toner cartridge is defective or out of toner.  | Redistribute the toner, if necessary. See page 7.6.<br>If necessary, replace the toner cartridge.  |
|   | The file may have blank pages.   | Check the file to ensure that it does not contain blank pages.   |
| Pages print, but are blank.<br>(continued)                                | Some parts, such as the controller or the board, may be defective.                       | Contact a service representative.  |
| The illustrations print incorrectly in Adobe Illustrator.                 | The setting in the software application is wrong.  | Print the document with selecting <b>Download as Bit Image</b> in the <b>Advanced Options</b> window of the Graphic properties.  |
| An error occurs repeatedly when you are printing with the USB connection. | When the USB mode is set to "Fast," some PC users may experience poor USB communication. | Change the USB mode to "Slow." To do so, follow these steps:<br><br>1. Press <b>Menu</b> on the control panel until "Machine Setup" appears on the top line of the display.<br><br>2. Press the scroll button (◀ or ▶) until "USB Mode" appears on the bottom line, and press <b>Enter</b> .<br><br>3. Press the scroll button (◀ or ▶) to select "Slow."<br><br>4. Press <b>Enter</b> to save the selection.<br><br>5. Press <b>Stop/Clear</b> to return to Standby mode. |






## Printing Quality Problems


The dirty inside of the machine or improper paper loading may reduce the print quality. See the table below to troubleshoot the problem.

| Condition  | Suggested solutions  |
|--|--|
| <b>Light or faded print</b><br> | <p>If a vertical white streak or faded area appears on the page:</p> <ul style="list-style-type: none"> <li>• The toner supply is low. You may be able to temporarily extend the toner cartridge life. See "Redistributing Toner" on page 7.6. If this does not improve the print quality, install a new toner cartridge.</li> <li>• The paper may not meet paper specifications; for example, the paper is too moist or too rough. See "Paper Specifications" on page B.6.</li> <li>• If the entire page is light, the print resolution setting is too low or Toner Save mode is on. Adjust the print resolution and turn the Toner Save mode off. See page 5.20 and page 1.19 respectively.</li> <li>• A combination of faded or smeared defects may indicate that the toner cartridge needs cleaning. See "Cleaning the Drum" on page 7.9.</li> </ul> |
| <b>Toner specs</b><br>         | <ul style="list-style-type: none"> <li>• The paper may not meet specifications; for example, the paper is too moist or too rough. See "Paper Specifications" on page B.6.</li> <li>• The transfer roller may be dirty. Clean the inside of your machine. See page 7.3.</li> <li>• The paper path may need cleaning. See "Cleaning the Drum" on page 7.9.</li> </ul>  |
| <b>Dropouts</b><br>           | <p>If faded areas, generally rounded, occur randomly on the page:</p> <ul style="list-style-type: none"> <li>• A single sheet of paper may be defective. Try reprinting the job.</li> <li>• The moisture content of the paper is uneven or the paper has moist spots on its surface. Try a different brand of paper. See "Paper Specifications" on page B.6.</li> <li>• The paper lot is bad. The manufacturing processes can cause some areas to reject toner. Try a different kind or brand of paper.</li> <li>• The toner cartridge may be defective. See "Vertical repetitive defects" on the next page.</li> <li>• If these steps do not correct the problems, contact a service representative.</li> </ul>   |

| Condition   | Suggested solutions  |
|---|--|
| <b>Vertical lines</b><br>                | <p>If black vertical streaks appear on the page:</p> <ul style="list-style-type: none"> <li>• The drum inside the toner cartridge has probably been scratched. Install a new toner cartridge. See "Installing the Toner Cartridge" on page 1.10.</li> </ul>  |
| <b>Gray background</b><br>               | <p>If the amount of background shading becomes unacceptable:</p> <ul style="list-style-type: none"> <li>• Change to a lighter weight pages. See "Paper Specifications" on page B.6.</li> <li>• Check the machine's environment; very dry (low humidity) or high humidity (higher than 80% RH) conditions can increase the amount of background shading.</li> <li>• Remove the old toner cartridge and install a new one. See "Installing the Toner Cartridge" on page 1.10.</li> </ul>   |
| <b>Toner smear</b><br>                  | <ul style="list-style-type: none"> <li>• Clean the inside of the machine. See page 7.3.</li> <li>• Check the paper type and quality. See "Paper Specifications" on page B.6.</li> <li>• Remove the toner cartridge and install a new one. See "Installing the Toner Cartridge" on page 1.10.</li> </ul>  |
| <b>Vertical repetitive defects</b><br> | <p>If marks repeatedly appear on the printed side of the page at even intervals:</p> <ul style="list-style-type: none"> <li>• The toner cartridge may be damaged. If a repetitive mark occurs on the page, print a cleaning sheet several times to clean the cartridge; see "Cleaning the Drum" on page 7.9. After the printout, if you still have the same problems, install a new toner cartridge. See "Installing the Toner Cartridge" on page 1.10.</li> <li>• Parts of the machine may have toner on them. If the defects occur on the back of the page, the problem will likely correct itself after a few more pages.</li> <li>• The fusing assembly may be damaged. Contact a service representative.</li> </ul> |

| Condition  | Suggested solutions  |
|--|--|
| <p><b>Background scatter</b></p>    | <p>Background scatter results from bits of toner distributed on the printed page.</p> <ul style="list-style-type: none"> <li>• The paper may be too damp. Try printing with a different batch of paper. Do not open packages of paper until necessary so that the paper does not absorb too much moisture.</li> <li>• If background scatter occurs on an envelope, change the printing layout to avoid printing over areas that have overlapping seams on the reverse side. Printing on seams can cause problems.</li> <li>• If background scatter covers the entire surface area of a printed page, adjust the print resolution through your software application or the printer properties.</li> </ul> |
| <p><b>Misformed characters</b></p>  | <ul style="list-style-type: none"> <li>• If characters are improperly formed and producing hollow images, the paper stock may be too slick. Try a different paper. See "Paper Specifications" on page B.6.</li> <li>• If characters are improperly formed and producing a wavy effect, the scanner unit may need service. For service, contact a service representative.</li> </ul>  |
| <p><b>Page skew</b></p>           | <ul style="list-style-type: none"> <li>• Ensure that the paper is loaded properly.</li> <li>• Check the paper type and quality. See "Paper Specifications" on page B.6.</li> <li>• Ensure that the paper or other material is loaded correctly and the guides are not too tight or too loose against the paper stack.</li> </ul>   |
| <p><b>Curl or wave</b></p>        | <ul style="list-style-type: none"> <li>• Ensure that the paper is loaded properly.</li> <li>• Check the paper type and quality. Both high temperature and humidity can cause paper curl. See "Paper Specifications" on page B.6.</li> <li>• Turn over the stack of paper in the paper tray. Also try rotating the paper 180° in the tray.</li> </ul>   |

| Condition   | Suggested solutions  |
|---|--|
| <p><b>Wrinkles or creases</b></p>          | <ul style="list-style-type: none"> <li>• Ensure that the paper is loaded properly.</li> <li>• Check the paper type and quality. See "Paper Specifications" on page B.6.</li> <li>• Turn over the stack of paper in the paper tray. Also try rotating the paper 180° in the tray.</li> </ul>  |
| <p><b>Back of printouts are dirty</b></p>  | <p>Check for leaking toner. Clean the inside of the machine. See page 7.3.</p>   |
| <p><b>Black pages</b></p>                 | <ul style="list-style-type: none"> <li>• The toner cartridge may not be installed properly. Remove the cartridge and reinsert.</li> <li>• The toner cartridge may be defective and need replacing. Install a new toner cartridge. See "Installing the Toner Cartridge" on page 1.10.</li> <li>• The machine may require repair. Contact a service representative.</li> </ul>   |
| <p><b>Loose toner</b></p>                | <ul style="list-style-type: none"> <li>• Clean the inside of the machine. See page 7.3.</li> <li>• Check the paper type and quality. See "Paper Specifications" on page B.6.</li> <li>• Install a new toner cartridge. See "Installing the Toner Cartridge" on page 1.10.</li> <li>• If the problem persists, the machine may require repair. Contact a service representative.</li> </ul>   |
| <p><b>Character Voids</b></p>            | <p>Character voids are white areas within the parts of characters that should be solid black:</p> <ul style="list-style-type: none"> <li>• If you are using transparencies, try another type of transparency. Because of the composition of the transparency, some character voids are normal.</li> <li>• You may be printing on the wrong surface on the paper. Remove the paper and turn it around.</li> <li>• The paper may not meet paper specifications. See "Paper Specifications" on page B.6.</li> </ul> |

| Condition  | Suggested solutions   |
|--|---|
| <b>Horizontal stripes</b><br> | <p>If horizontally aligned black streaks or smears appear:</p> <ul style="list-style-type: none"> <li>• The toner cartridge may be installed improperly. Remove the cartridge and reinsert.</li> <li>• The toner cartridge may be defective. Install a new toner cartridge. See "Installing the Toner Cartridge" on page 1.10.</li> <li>• If the problem persists, the machine may require repair. Contact a service representative.</li> </ul> |

## Fax Problems *(For SCX-4216F)*

| Condition  | Suggested solutions  |
|--|--|
| The machine is not working, there is no display and the buttons are not working. | <ul style="list-style-type: none"> <li>• Unplug the power cord and plug it in again.</li> <li>• Ensure that there is power to the electrical receptacle.</li> </ul>  |
| No dial tone sounds.   | <ul style="list-style-type: none"> <li>• Check that the phone line is connected properly.</li> <li>• Check that the phone socket in the wall is working by plugging in another phone.</li> </ul>   |
| The numbers stored in the memory do not dial correctly.                          | Make sure that the numbers are stored in the memory correctly. Print a Phonebook list, referring to the Facsimile User's Guide.  |
| The document does not feed into the machine.                                     | <ul style="list-style-type: none"> <li>• Make sure that the document is not wrinkled and you are putting it in correctly. Check that the document is the right size, not too thick or thin.</li> <li>• Make sure that the ADF (Automatic Document Feeder) cover is firmly closed.</li> </ul> |
| Faxes are not received automatically.  | <ul style="list-style-type: none"> <li>• The FAX mode should be selected.</li> <li>• Make sure that there is paper in the tray.</li> <li>• Check to see if the display shows "Memory Full."</li> </ul>   |
| The machine does not send.   | <ul style="list-style-type: none"> <li>• Make sure that the document is loaded in the ADF or on the document glass.</li> <li>• "TX" should show up on the display.</li> <li>• Check the other fax machine you are sending to, to see if it can receive your fax.</li> </ul>                  |



| Condition   | Suggested solutions  |
|---|--|
| The incoming fax has blank spaces or is received with a poor-quality.                                   | <ul style="list-style-type: none"> <li>• The fax machine sending you the fax may be faulty.</li> <li>• A noisy phone line can cause line errors.</li> <li>• Check your machine by making a copy.</li> <li>• The toner cartridge may be empty. Replace the toner cartridge, referring to page 7.7.</li> </ul> |
| Some of the words on a incoming fax are stretched.  | The fax machine sending you the fax had a temporary document jam.  |
| There are lines on the documents you send.  | Check your scan glass for marks and clean it. See page 7.4.  |
| The machine dials a number, but a connection with another fax machine fails.                            | The other fax machine may be turned off, out of paper, or cannot answer incoming calls. Speak with the other machine operator and ask her/him to sort out the problem.   |
| Documents are not stored in the memory.   | There may not be enough memory to store the document. If the display shows a "Memory Full" message, delete any documents you no longer need from the memory and then restore the document.   |
| Blank areas appear at the bottom of each page or on other pages, with a small strip of text at the top. | You may have chosen the wrong paper settings in the user option setting. See page 1.18 for the paper tray and page 3.10 for the Bypass tray.   |

## Copying Problems

| Condition   | Suggested solutions  |
|---|--|
| Copies are too light or too dark.                               | <ul style="list-style-type: none"> <li>• If the original is light, use the <b>Contrast</b> button to darken the background of the copies.</li> <li>• If the original is dark, use the <b>Contrast</b> button to lighten the background of the copies.</li> </ul>   |
| Smears, lines, marks or spots appears on copies.                | <ul style="list-style-type: none"> <li>• If defects are on the original, press the <b>Contrast</b> button to lighten the background of your copies.</li> <li>• If no defects are on the original, clean the document glass and underside of the document cover. See page 7.4.</li> </ul>   |
| Copy image is skewed.   | <ul style="list-style-type: none"> <li>• Ensure that the original is positioned correctly on document glass.</li> <li>• Check that the copy paper is loaded correctly.</li> </ul>  |
| Blank copies print out.   | Ensure that the original is face down on the document glass or face up in the Automatic Document Feeder (for SCX-4116/4216F only).   |
| Image rubs off the copy easily.                                 | <ul style="list-style-type: none"> <li>• Replace the paper in the paper tray with paper from a new package.</li> <li>• In high humidity areas, do not leave paper in the machine for extended periods of time.</li> </ul>  |
| Frequent copy paper jams occurs.                                | <ul style="list-style-type: none"> <li>• Fan the stack of paper, then turn it over in the paper tray. Replace the paper in the tray with a fresh supply. Check/adjust the paper guides, if necessary.</li> <li>• Ensure that the paper is the proper paper weight. 75 g/m<sup>2</sup> (20 lb) bond paper is recommended.</li> <li>• Check for copy paper or pieces of copy paper remaining in the machine after a paper jam has been cleared.</li> </ul> |
| Fewer copies from the toner cartridge than expected prints out. | <ul style="list-style-type: none"> <li>• Your originals may contain pictures, solids or heavy lines. For example, your originals may be forms, newsletters, books or other documents that use more toner.</li> <li>• The machine may be turned frequently on and off.</li> <li>• The document cover may be left open while copies are being made.</li> </ul>   |

## Scanning Problems

| Condition  | Suggested solutions  |
|--|--|
| The scanner does not work.   | <ul style="list-style-type: none"> <li>• Make sure that you place the document to be scanned face down on the document glass, or face up in the Automatic Document Feeder (for SCX-4116/4216F).</li> <li>• There may not be enough available memory to hold the document you want to scan. Try the Prescan function to see if that works. Try lowering the scan resolution rate.</li> <li>• Check that the USB or parallel cable is connected properly.</li> <li>• Make sure that the USB or parallel cable is not defective. Switch the cable with a known good cable. If necessary, replace the cable.</li> <li>• If you are using a parallel cable, ensure that it is compliant with the IEEE 1284 standard.</li> <li>• Check that the scanner is configured correctly. Check scan setting in the SmarThru Configuration or the application you want to use to make certain that the scanner job is being sent to the correct port, for example, LPT1.</li> </ul> |
| The unit scans very slowly.  | <ul style="list-style-type: none"> <li>• Check if the machine is printing received data. Scan the document after the current job is completed.</li> <li>• Graphics are scanned more slowly than text.</li> <li>• Communication speed becomes slow in scan mode because of the large amount of memory required to analyze and reproduce the scanned image. Set your computer to ECP printer mode through BIOS setting. It will help to increase the speed. For details on how to set BIOS, refer to your computer User's Guide.</li> </ul>  |
| Message appears on your computer screen: "Scanner is busy receiving or printing data. When the current job is completed, try again." | There may be a copying or printing job in progress. When the current job is complete, try the job again.   |

## Common Macintosh Problems

| Problem  | Possible Cause and Solution  |
|--|--|
| The printer driver icon does not appear in Chooser.  | Software is not installed correctly. <ul style="list-style-type: none"><li>• Make sure that you are using a high-quality cable.</li><li>• Make sure that the printer is on the correct network. Select <b>Network</b> or <b>AppleTalk Control Panel</b> from <b>Control Panels</b> in the <b>Apple</b> menu and then choose the correct network.</li></ul>   |
| The printer name does not appear in the <b>Select a PostScript Printer</b> box in the Chooser. | <ul style="list-style-type: none"><li>• Make sure that the cables are connected correctly and the printer is turned on.</li><li>• Check if "Ready" appears on the display of the control panel. If not, clear the problem depending on the error message; see page 8.10.</li><li>• Make sure that the correct printer driver has been selected in Chooser.</li><li>• If the printer resides on a network with multiple zones, make sure that the correct zone is selected in the AppleTalk Zones box in Chooser.</li><li>• Make sure that AppleTalk is on; the button next to <b>Active</b> is selected in Chooser. You may need to restart the computer to activate the change.</li></ul> |

# **MEMO**





# PRINTING FROM A MACINTOSH

This chapter includes:

- **Installing Software for Macintosh**
- **Printing a Document**
- **Using Advanced Printing Features**

---

# Installing Software for Macintosh

Your machine supports Macintosh systems with a built-in USB interface. When you print a file from a Macintosh computer, you can use the SPL driver to support your machine's major printing features.

## System Requirements

To use your machine and its software with a Macintosh, your system should have:

### Macintosh Hardware Requirement:


- One of the following Macintosh models:
  - Power Macintosh series
  - Power Macintosh G3, G4
  - iMac series
  - PowerBook series
  - iBook series
- USB interface

### Macintosh System Requirement:

System 8.6 or later

## Installing Software

- 1 Connecting the machine to the USB port of the computer requires a certified USB cable. You will need to buy a USB 1.1 compliant cable that is within 3 m in length. Connect it to the USB connector on your machine.





---

**NOTE:** If you are using a USB hub, connect the machine's cable to the first tier of the hub, or the machine may malfunction. If the machine doesn't work with the hub, connect it directly to the USB port.

---

- 2 Turn on your computer and machine.
- 3 Insert the CD-ROM which came with your machine into the CD-ROM drive.
- 4 Double-click **SCX-4x16** on your Macintosh desktop.
- 5 Double-click the **West** folder.
- 6 Double-click the **Samsung Laser Printer Installer** icon next to each language to select the correct one.
- 7 Click **Continue**, and then click **Continue**.
- 8 The Samsung Laser Printer Installer window opens. Select the installation type.  
  
The window provides the following two options for software installation:
  - Easy Install** (recommended method): This option installs the SPL driver.
  - Custom Install** : This option allows you to choose which components will be installed, the SPL driver or the Adobe Acrobat Reader program for opening the User's Guide.
- 9 Click **Install**.  
  
If other programs are operating, the alert message appears. Click **Continue** to install the software or click **Cancel**, close other programs and install the software.
- 10 After the installation is finished, click **Restart**.



## Choosing Your Printer


- 1 From the **Apple** menu, select **Chooser**.
- 2 From the left pane of the Chooser window, click **SAMSUNG SPL II**. Then your printer name will appear in the right pane of the Chooser window.
- 3 Click **SAMSUNG SPL II** and close the Chooser window.
- 4 The message window indicating that you have changed your current printer appears. Click **OK**.
- 5 An SAMSUNG SPL II printer icon will be created on your desktop.

---


## Printing a Document

When you print with a Macintosh computer, you need to check the printer software setting in each application you use. Follow these steps to print from a Macintosh:


- 1 Open a Macintosh application and select a file you want to print.
- 2 Open the **File** menu, and click **Page Setup (Document Setup** in some applications).
- 3 Choose your paper size, orientation, paper type and other options and click **OK**.



Choose **Watermark** to add a watermark to each page in your document to emphasize its purpose or indicate how it should be handled. For details on the watermark options, see page 5.13.



- 4 Open the **File** menu and click **Print**. You will see the SAMSUNG SPL II Printer window.
- 5 Choose the number of copies and indicate which pages you want to print.



- 6 Click **Print** when you finish setting the options.


## Using Advanced Printing Features

The SAMSUNG SPL II Printer window contains five categories of advanced properties. Listed below is the name of each property.


- Darkness/Quality
- Layout
- Color
- Background Printing
- Paper Source

The following figures display each property in the SAMSUNG SPL II Printer window.


### Darkness/Quality




### Layout



## Color




## Background Printing



Select priority for your print job in the queue of jobs waiting to print, click one of the following:

- **Urgent:** to print before any Normal priority job.
- **Normal:** to print in the order the job is received.
- **Print at:** to print at the specific time you enter in the day and time in the fields to the right.
- **Put document on hold:** to hold the print job in the print queue until you are ready to release it.

## Paper Source





## **SPECIFICATIONS**

This chapter includes:

- **General Specifications**
- **Scanner and Copy Specifications**
- **Printer Specifications**
- **Facsimile Specifications (For SCX-4216F)**
- **Paper Specifications**

# General Specifications

| Item   | Description  |
|--|--|
| Automatic document feeder (for SCX-4116/4216F) | Up to 30 sheets (20 lb, 75 g/m <sup>2</sup> )  |
| ADF Document size (for SCX-4116/4216F)         | Width: 142 to 216 mm (5.6 to 8.5 inches)<br>Length: 148 to 356 mm (5.8 to 14 inches)   |
| Paper input capacity                           | Paper tray: 250 sheets (weight: 75 g/m <sup>2</sup> , 20 lb)<br>Bypass tray: 1 sheets (weight: 75 g/m <sup>2</sup> , 20 lb)  |
| Paper output capacity                          | Front output tray: 150 sheets (face down)<br>Rear output slot: 1 sheet (face up)   |
| Paper type                                     | Paper tray: Plain paper (60 ~ 90 g/m <sup>2</sup> , 16 ~ 24 lb)<br>Bypass tray: Plain paper, Transparencies, Labels, Card, Post card, Envelopes (60 ~ 120 g/m <sup>2</sup> , 16 ~ 32 lb) |
| Consumables                                    | 1-piece toner cartridge system   |
| Power requirements                             | 110 ~ 120 VAC, 50/60 Hz, 5A<br>220 ~ 240 VAC, 50/60 Hz, 2.5A   |
| Power consumption                              | Sleep mode: 19 W<br>Standby mode: 85 W/ 95 W<br>Average: 320 W /350 W  |
| Noise  | Warm-up: 50 dB<br>Standby mode: 35 dB<br>Printing: 55 dB   |
| Warm-up Time                                   | 110 ~ 120 VAC: 30 seconds<br>220 ~ 240 VAC: 0 seconds  |
| Operating conditions                           | Temperature: 50 °F to 89 °F (10 °C to 32 °C)<br>Humidity: 20 % to 80 % RH  |
| LCD  | 16 characters x 2 lines  |
| Toner cartridge life                           | 3,000 pages (for starter, 1,000 pages) @ IDC 5 % coverage  |
| SET dimension (W x D x H)                      | SCX-4116/4216F: 474 x 436 x 417 mm<br>SCX-4016: 474 x 436 x 353 mm   |

| Item           | Description   |
|----------------|---|
| Weight         | Net: 13 (SCX-4116/4216F)/11.7 (SCX-4016) Kg<br>(including consumables)<br>Gross: 17 (SCX-4116/4216F)/15.7 (SCX-4016) Kg<br>(including consumables, accessories and package) |
| Package Weight | Paper: 2.7 Kg<br>Plastic: 0.7 Kg  |

## Scanner and Copier Specifications

| Item                      | Description   |
|---------------------------|---|
| Compatibility             | TWAIN standard  |
| Scanning method           | Sheet-fed and Flat-bed CCD (Charge Coupled Device) module   |
| Resolution                | Optical: 600 dpi (Mono and Color)<br>Enhanced: 4,800 dpi  |
| Effective scanning length | Platen: 297 mm (11.7 in.)<br>ADF (for SCX-4116/4216F): 356 (14 in.)   |
| Effective scanning width  | 8.2 inches (208 mm)   |
| Color bit depth           | Internal: 32 bit<br>External: 24 bit  |
| Mono bit depth            | 1 bit for Text mode<br>8 bit for Gray mode  |
| Scan speed (Text mode)    | Platen: 23 seconds<br>ADF (SCX- 4116/4216F): 25 seconds   |
| Copy speed                | 17 copies per minute (Letter)   |
| Paper size                | Letter, A4, Legal   |
| Copy resolution           | Platen: 600 x 300 (Text, Mixed) / 600 x 600 (Photo)<br>ADF (for SCX-4116/4216F): 600 x 300 (Text, Mixed, Photo) |
| Zoom rate                 | Platen: 25 ~ 400 %<br>ADF (for SCX-4116/4216F): 25 ~ 100 %  |



| Item            | Description             |
|-----------------|-------------------------|
| Multiple copies | 99 pages                |
| Grayscale       | 256 levels              |
| HPHR            | Zero Warm Up Technology |

## Printer Specifications

| Item                | Description  |
|---------------------|--|
| Printing method     | Laser Beam Printing  |
| Printing speed      | 17 pages per minute (Letter)   |
| Paper size          | Paper tray: Letter, A4, Legal, Folio, A5, A6<br>Bypass tray: Letter, Legal, A4, Folio, Executive, A5, A6, A6 card, Post Card 4x6, HagaKi, Envelope 7-3/4, Envelope 9, Envelope 10, Envelope DL, Envelope C5, Envelope C6, Envelope B5<br>* Min.: 76 x 127 mm (3 x 5 in.)<br>Max.: 216 x 356 (8.5 x 14 in.) |
| Print resolution    | 600 x 600 dpi  |
| Emulation           | SPL (GDI)  |
| PC Interface        | IEEE 1284, USB 1.1   |
| Compatibility       | Windows 95/98/2000/NT 4.0/Me/XP<br>Macintosh 8.6 or higher   |
| First printing time | Standby mode: 12 seconds<br>Power save mode: 42 seconds  |

## Facsimile Specifications *(For SCX-4216F)*

| Item                    | Description   |
|-------------------------|---|
| Compatibility           | ITU-T Group 3, ECM  |
| Applicable line         | Public Switched Telephone Network (PSTN) or behind PABX   |
| Data coding             | MH/MR/MMR (ECM Mode) and JPEG for color fax transmission  |
| Modem speed             | 33600/28800/21600/19200/14400/12000/9600/7200/4800/2400 bps with fall back  |
| Transmission speed      | Approx. 3 seconds/page<br>* Transmission time applies to memory transmission of text data with ECM compression using only ITU-T No.1 Chart. |
| Scanning speed          | Platen: approx. 3 seconds/letter (at standard fax resolution mode)<br>ADF: approx. 5 seconds/letter (at standard fax resolution mode)       |
| Maximum document length | Platen: 297 mm<br>ADF: 1.5 m  |
| Paper size              | Letter, A4, Legal   |
| Resolution              | Standard: 203 x 98 dpi<br>Fine: 203 x 196 dpi<br>Super Fine: 300 x 300 dpi / 203 x 392 dpi<br>Photo: 203 x 196 dpi<br>Color: 200 x 200 dpi  |
| User Memory             | 4 MB (320 pages)  |
| Halftone                | 256 levels  |
| Auto dialer             | Speed dialing (registration for 60 numbers)   |

# Paper Specifications

## Overview

Your machine accepts a variety of print materials, such as cut-sheet paper (including up to 100% recycled fiber content paper), envelopes, labels, transparencies and custom-size paper. Properties, such as weight, composition, grain and moisture content, are important factors affecting the machine's performance and the output quality. Paper that does not meet the guidelines outlined in this User's Guide can cause the following problems:

- Poor print quality
- Increased paper jams
- Premature wear on the machine.

---

### NOTES:

- Some paper may meet all of the guidelines in this guide and still not produce satisfactory results. This may be the result of improper handling, unacceptable temperature and humidity levels, or other variables over which Samsung has no control.
  - Before purchasing large quantities of paper, insure the paper meets the requirements specified in this User's Guide.
- 

**CAUTION:** Using paper that does not meet these specifications may cause problems, requiring repairs. These repairs are not covered by the Samsung warranty or service agreements.

---

## Supported Sizes of Paper

| Paper     | Dimensions <sup>1</sup>          | Weight   | Capacity <sup>2</sup>   |
|-----------|----------------------------------|--|---|
| Letter    | 8.5 X 11 in.<br>(216 X 279 mm)   | <ul style="list-style-type: none"><li>• 60 to 105 g/m<sup>2</sup> bond (16 to 28 lb) for the paper tray</li><li>• 60 to 120 g/m<sup>2</sup> bond (16 to 32 lb) for the Bypass tray</li></ul> | <ul style="list-style-type: none"><li>• 250 sheets of 75 g/m<sup>2</sup> bond (20 lb) paper for the paper tray</li><li>• 1 sheet of paper for the Bypass tray</li></ul> |
| A4        | 210 X 297 mm<br>(8.3 X 11.7 in.) |  |   |
| Executive | 7.25 X 10.5 in. (191 X 267 mm)   |  |   |
| Legal     | 8.5 X 14 in.<br>(216 X 356 mm)   |  |   |
| Folio     | 216 X 330 mm<br>(8.5 X 13 in.)   |  |   |

| Paper                 | Dimensions <sup>1</sup>                               | Weight   | Capacity <sup>2</sup>  |
|-----------------------|---|--|--|
| Minimum size (custom) | 76 x 127 mm<br>(3 x 5 in)                             | 60 to 120 g/m <sup>2</sup><br>bond (16 to 32 lb) | <ul style="list-style-type: none"> <li>1 sheet of paper for the Bypass tray</li> </ul> |
| Maximum size (Legal)  | 216 x 356mm<br>(8.5 x 14 in)                          |  |  |
| Transparency          | Same minimum and maximum paper sizes as listed above. | 138 to 146 g/m <sup>2</sup>                      |  |
| Labels                |   | 120 to 150 g/m <sup>2</sup>                      |  |
| Cards                 |   | 90 to 163 g/m <sup>2</sup>                       |  |
| Envelopes             |   | 75 to 90 g/m <sup>2</sup>                        |  |

1. The machine supports a wide range of media sizes. See "Size, Input Sources and Capacities" on page 3.2.
2. Capacity may vary depending on print materials' weight and thickness, and environmental conditions.



**NOTE:** You may experience jams when using print materials with a length of less than 127 mm (5 in.). For optimum performance, ensure that you are storing and handling the paper correctly. Please refer to "Printer and Paper Storage Environment" on page B.9.

## Guidelines for Using Paper

For the best result, use conventional 75 g/m<sup>2</sup> (20 lb) paper. Ensure that the paper is of good quality, and free of cuts, nicks, tears, spots, loose particles, dust, wrinkles, voids, and curled or bent edges.

If you are unsure of what type of paper you are loading, such as bond or recycled paper, check the label on the package.

The following problems may cause print quality deviations, jamming or even damage to the printer.

| Symptom   | Problem with Paper   | Solution   |
|---|--|--|
| Poor print quality or toner adhesion, problems with feeding | Too moist, too rough, too smooth or embossed; faulty paper lot | Try another kind of paper, between 100 ~ 400 Sheffield, 4 ~ 5 % moisture content.                          |
| Dropout, jamming, curl                                      | Stored improperly  | Store paper flat in its moisture-proof wrapping.   |
| Increased gray background shading/printer wear              | Too heavy  | Use lighter paper, use the rear output slot.   |
| Excessive curl problems with feeding                        | Too moist, wrong grain direction or short-grain construction   | <ul style="list-style-type: none"> <li>Use the rear output slot.</li> <li>Use long-grain paper.</li> </ul> |

| Symptom                    | Problem with Paper      | Solution                                       |
|----------------------------|-------------------------|--|
| Jamming, damage to printer | Cutouts or perforations | Do not use paper with cutouts or perforations. |
| Problems with feeding      | Ragged edges            | Use good quality paper.                        |



#### NOTES:

- Do not use letterhead paper printed with low-temperature inks, such as those used in some types of thermography.
- Do not use raised or embossed letterhead.
- The printer uses heat and pressure to fuse toner to the paper. Insure that any colored paper or preprinted forms use inks that are compatible with this fusing temperature (200 °C or 392 °F for 0.1 second).

## Paper Specifications

| Category             | Specifications  |
|----------------------|---|
| Acid Content         | 5.5 pH or lower   |
| Caliper              | 0.094 ~ 0.18 mm (3.0 ~ 7.0 mils)  |
| Curl in Ream         | Flat within 5 mm (0.02 in.)   |
| Cut Edge Conditions  | Cut with sharp blades with no visible fray.   |
| Fusing Compatibility | Must not scorch, melt, offset or release hazardous emissions when heated to 200 °C (392 °F) for 0.1 second. |
| Grain                | Long Grain  |
| Moisture Content     | 4 % ~ 6 % by weight   |
| Smoothness           | 100 ~ 400 Sheffield   |

## Paper Output Capacity

| Output Location       | Capacity   |
|-----------------------|--|
| Face-down output tray | 150 sheets of 75 g/m <sup>2</sup> bond (20 lb) paper |
| Face-up output slot   | 1 sheet of 75 g/m <sup>2</sup> bond (20 lb) paper    |

## Printer and Paper Storage Environment

Paper storage environmental conditions directly affect the feed operation.

Ideally, the machine and paper storage environment should be at or near room temperature, and not too dry or humid. Remember that paper is hygroscopic; it absorbs and loses moisture rapidly.

Heat works with humidity to damage paper. Heat causes the moisture in paper to evaporate, while cold causes it to condense on the sheets. Heating systems and air conditioners remove most of the humidity from a room. As paper is opened and used, it loses moisture, causing streaks and smudging. Humid weather or water coolers can cause the humidity to increase in a room. As paper is opened and used it absorbs any excess moisture, causing light print and dropouts. Also, as paper loses and gains moisture it can become distorted. This can cause paper jams.

Care should be taken not to purchase more paper than can be used in a short time (about 3 months). Paper stored for long periods may experience heat and moisture extremes, which can cause damage. Planning is important to prevent damage to large supplies of paper.

Unopened paper in sealed reams can remain stable for several months before use. Opened packages of paper have more potential for environment damage, especially if they are not wrapped with a moisture-proof barrier.

The paper storage environment should be properly maintained to ensure optimum performance. The required condition is 20 to 24 °C (68 to 75 °F), with a relative humidity of 45 % to 55 %. The following guidelines should be considered when evaluating the paper's storage environment:

- Paper should be stored at or near room temperature.
- The air should not be too dry or too humid.
- The best way to store an opened ream of paper is to rewrap it tightly in its moisture-proof wrapping. If the machine environment is subject to extremes, unwrap only the amount of paper to be used during the day's operation to prevent unwanted moisture changes.

# MEMO



# INDEX

## Numerics

2/4-up, special copy 4.11

2-side, special copy 4.10

## A

ADF, load 4.4

auto fit, special copy 4.8

## B

bypass tray, use 3.8

## C

cancel

copy 4.3

print 5.5

scan 6.5

CCD power save mode, use 1.20

clone, special copy 4.9

collation, special copy 4.10

connection

AC power 1.17

parallel 1.16

telephone line cord 1.15

USB 1.16

consumables 7.10

contrast, copy 4.6

control panel 1.7

copy

contrast 4.6

default setting, change 4.13

from ADF 4.4

from document glass 4.2

image 4.6

number of pages 4.7

special features 4.8

time out, set 4.14

## D

display language, change

control panel 1.17

document

jam, clear 8.2

load in ADF 4.4

load on document glass 4.2

document glass

clean 7.4

load 4.2

drum, clean 7.9

## E

error messages 8.10

## F

Favorite setting, use 5.6

fit to page

copy 4.8

print 5.11

front output tray, use 3.5

## G

graphic properties, set 5.20

## H

help, use 5.6

## I

install

Macintosh software A.2

toner cartridge 1.10

Windows software 2.4



## J

jam, clear  
    document 8.2  
    paper 8.4

## M

Macintosh  
    common problems 8.25  
    document, print A.4  
    driver, install A.2  
memory, clear 7.2  
MFP driver  
    install 2.4  
    uninstall 2.9

## N

network printer, set 5.22  
n-up (multiple pages per sheet)  
    copy 4.11  
    print 5.8

## O

orientation, print 5.3  
output location, select 3.4  
overlay, use 5.16

## P

paper guidelines 3.3  
paper jam, clear 8.4  
paper level indicator 3.7  
paper load  
    in bypass tray 3.8  
    in paper tray 1.12  
paper load capacity 3.2  
paper properties, set 5.7  
paper size, set  
    bypass tray 3.10  
    paper tray 1.18  
    print 5.7  
paper source, set 5.8  
paper type, set  
    bypass tray 3.10  
    paper tray 1.18  
    print 5.8  
parallel, connect 1.16  
poster  
    copy 4.12  
    print 5.12  
power save mode, use 1.19

print order, set 5.4  
print resolution 5.20  
printer driver  
    install in Windows 2.4  
    install in Macintosh A.2  
    uninstall 2.9  
printing  
    fitting to a selected paper size 5.11  
    from Macintosh A.4  
    from Windows 5.2  
    multiple pages on one sheet 5.8  
    posters 5.12  
    reduced or enlarged document  
        5.10  
    using overlays 5.16  
    watermarks 5.13  
problem, solve  
    copying 8.23  
    error messages 8.10  
    fax 8.21  
    paper feeding 8.13  
    printing 8.14  
    printing quality 8.17  
    scanning 8.24  
problem, solving  
    Macintosh 8.25

## R

rear output slot, use 3.5  
reduced/enlarged  
    copy 4.7  
    print 5.10

## S

scan driver  
    install 2.4  
    uninstall 2.9  
SmarThru  
    install 2.4  
    uninstall 2.10  
specifications  
    facsimile B.5  
    general B.2  
    paper B.6  
    printer B.4  
    scanner and copier B.3  
system requirements  
    Macintosh A.2  
    Windows 2.3

## T

- tel line, connect 1.15
- toner cartridge
  - install 1.10
  - life 7.6
  - redistribute 7.6
  - replace 7.7
- toner save mode, use 1.19
- TWAIN, scan 6.5

## U

- unistall
  - MFP driver 2.9
  - SmarThru 2.10
  - using CD-ROM 2.12
- USB
  - connect 1.16
  - mode, change 8.16
- USB driver, install
  - in Windows 98/Me 2.8

## W

- watermarks, use 5.13

## Z

- zoom rate, copy 4.7

The Samsung logo is located in the top left corner, consisting of the word "SAMSUNG" in a bold, sans-serif font, enclosed within a white oval shape.

User's Guide

# ***Digital Laser Facsimile***

## ***SCX-4216F***

**For UK customers:**

**To reorder your consumables**  
Call 0800 3164060

**For Technical Assistance**  
Call 0870 2420303

# CONTENTS

## *Chapter 1:* **GETTING STARTED**

|   |      |
|---|------|
| Control Panel Functions .....                               | 1.2  |
| Setting the Machine ID .....                                | 1.4  |
| Entering Characters Using the Number Keypad ...             | 1.5  |
| Setting the Date and Time .....                             | 1.7  |
| Changing the Clock Mode .....                               | 1.8  |
| Setting Sounds .....  | 1.8  |
| Speaker Control, Ringer, Key Sound and<br>Alarm Sound ..... | 1.9  |
| Speaker Volume .....  | 1.9  |
| Setting the Dial Mode .....                                 | 1.10 |
| Using the Toll Save Mode .....                              | 1.11 |
| Setting up the Fax System .....                             | 1.12 |
| Changing the Fax Setup options .....                        | 1.12 |
| Available Fax Setup Options .....                           | 1.12 |

## *Chapter 2:* **GENERAL FAX FUNCTIONS**

|   |     |
|---|-----|
| Sending a Fax .....                       | 2.2 |
| Preparing Documents for Faxing .....      | 2.2 |
| Loading an Original Document .....        | 2.2 |
| Adjusting the Document Resolution .....   | 2.4 |
| Sending a Fax Automatically .....         | 2.5 |
| Sending a Fax Manually .....              | 2.6 |
| Confirming Transmission .....             | 2.6 |
| Automatic Redialing .....                 | 2.7 |
| Receiving a Fax .....                     | 2.7 |
| About Receiving Modes .....               | 2.7 |
| Loading Paper for Receiving Faxes .....   | 2.8 |
| Receiving Automatically in Fax Mode ..... | 2.8 |
| Receiving Manually in Tel Mode .....      | 2.8 |
| Receiving Faxes in the Memory .....       | 2.8 |

### **Chapter 3: AUTOMATIC DIALING**

|   |     |
|---|-----|
| Speed Dialing .....   | 3.2 |
| Storing a Number for Speed Dialing .....                                | 3.2 |
| Sending a Fax using a Speed Number .....                                | 3.3 |
| Group Dialing .....   | 3.4 |
| Setting Group Dial .....  | 3.4 |
| Editing Group Dial Numbers .....  | 3.5 |
| Sending a Fax Using Group Dialing<br>(Multi-address Transmission) ..... | 3.6 |
| Searching for a Number in the Memory .....                              | 3.7 |
| Searching Sequentially through the Memory .....                         | 3.7 |
| Searching with a Particular First Letter .....                          | 3.7 |
| Printing a Phonebook List .....   | 3.8 |

### **Chapter 4: OTHER WAYS TO FAX**

|   |     |
|---|-----|
| Redialing .....                           | 4.2 |
| Sending Broadcasting Faxes .....          | 4.2 |
| Sending a Delayed Fax .....               | 4.3 |
| Sending a Priority Fax .....              | 4.5 |
| Adding Documents To a Scheduled Fax ..... | 4.7 |
| Canceling a Scheduled Fax .....           | 4.8 |

### **Chapter 5: ADDITIONAL FEATURES**

|                                      |     |
|--------------------------------------|-----|
| Using the Secure Fax Mode .....      | 5.2 |
| Printing Reports .....               | 5.3 |
| Using Advanced Fax Settings .....    | 5.5 |
| Changing Setting Options .....       | 5.5 |
| Advanced Fax Setting Options .....   | 5.6 |
| Using the Remote Control Panel ..... | 5.7 |

# **MEMO**


# 1











## GETTING STARTED

The following topics are included:












- **Control Panel Functions**
- **Setting the Machine ID**
- **Setting the Date and Time**
- **Setting Sounds**
- **Setting the Dial Mode**
- **Using the Toll Save Mode**
- **Setting up the Fax System**

# Control Panel Functions



|                                     |   |  |
|-------------------------------------|---|--|
| <b>1</b><br><b>COPY</b><br><b>*</b> |    | Adjusts the brightness of the documents for the current copy job.  |
|                                     |    | Selects the document type for the current copy job.  |
|                                     |    | Allows you to use special copy features, such as Clone, Collation, Autofit, 2-side, N-up (multiple pages on a sheet) and Poster copying. |
|                                     |  | Makes a copy smaller or larger than the original.  |
|                                     |  | Selects the number of copies.  |
| <b>2</b>                            |  | Displays the current status and prompts during an operation.   |
|                                     |  | Turns on when the toner cartridge is empty.  |
| <b>3</b>                            |  | Scrolls through the options available for the selected menu item.  |
|                                     |  | Confirms the selection on the display.   |
|                                     |  | Enters menu functions and scrolls through menu items.  |



|                       |   |   |
|-----------------------|---|---|
| 3                     | Upper Level<br>      | Sends you back to the upper menu level.   |
|                       | Stop / Clear<br>     | Stops an operation at any time.<br>In Standby mode, clears/cancels the copy options, such as the contrast, the image setting, the copy size and the number of copies.   |
|                       | Start Copy / Fax<br> | Starts a job.   |
| 4                     |                      | Dials a number or enters alphanumeric characters.   |
| 5<br>F<br>A<br>X      | Resolution<br>       | Adjusts the resolution of the documents for the current fax job.  |
|                       | Broadcasting<br>     | Allows you to send a fax to multiple destinations.  |
|                       | Phonebook<br>        | <ul style="list-style-type: none"> <li>Allows you to store frequently-dialed fax numbers using a one or two-digit speed dial or group number for automatic dialing and edit the stored numbers.</li> <li>Allows you to print a Phonebook list.</li> </ul> |
|                       | Redial/Pause<br>   | Redials the last number in Standby mode or insert a pause into a fax number in edit mode.   |
|                       | On Hook Dial<br>   | Engages the telephone line.   |
| 6<br>S<br>A<br>V<br>E | Toner Save<br>     | Allows you to save on toner by using less toner to print a document.  |
|                       | Toll Save<br>      | Allows you to save on call costs by sending a fax at a preset toll-saving time. Using this feature, you can take advantage of lower long distance rates at night, for example.  |

\*. For details about copy features, refer to the MFP User's Guide.

**6** Press **Enter** when the name on the display is correct.

**7** Press **Stop/Clear** to return to Standby mode.

## Entering Characters Using the Number Keypad

As you perform various tasks, you will need to enter names and numbers. For example, when you set up your machine, you enter your name (or your company's name) and telephone number. When you store one or two digit speed dial or group dial numbers, you may also enter the corresponding names.

To enter alphanumeric characters:

- 1** When you are prompted to enter a letter, locate the button labeled with the character you want. Press the button until the correct letter appears on the display.

For example, to enter the letter **O**, press **6**, labeled with "MNO."

Each time you press **6**, the display shows a different letter, **M**, **N**, **O** and finally **6**.



You can enter special characters (space, plus sign, etc.). For details, see "Keypad Letters and Numbers" on page 1.6.

- 2** To enter additional letters, repeat Step 1.

If the next letter is printed on the same button, move the cursor by pressing the ► button and then press the button labeled with the letter you want. The cursor will move to the right and the next letter will appear on the display.

You can enter a space by pressing the # button.

- 3** When you finish entering letters, press **Enter**.

## Keypad Letters and Numbers

| Key      | Assigned numbers, letters or characters |
|----------|---|
| <b>1</b> | 1 Space                                 |
| <b>2</b> | A B C 2                                 |
| <b>3</b> | D E F 3                                 |
| <b>4</b> | G H I 4                                 |
| <b>5</b> | J K L 5                                 |
| <b>6</b> | M N O 6                                 |
| <b>7</b> | P Q R S 7                               |
| <b>8</b> | T U V 8                                 |
| <b>9</b> | W X Y Z 9                               |
| <b>0</b> | + - , . ' / * # & 0                     |

## Changing Numbers or Names

If you make a mistake while entering a number or name, press the ◀ button to delete the last digit or character. Then enter the correct numbers or characters.

## Inserting a Pause

With some telephone systems, you must dial an access code (9, for example) and listen for a second dial tone. In such cases, you must insert a pause in the telephone number. You can insert a pause while you are setting up speed dial numbers.

To insert a pause, press **Redial/Pause** at the appropriate place while entering the telephone number. A “-” will appear on the display at the corresponding location.

## Setting the Date and Time


1

All of your faxes will have the date and time printed on them.



**NOTE:** If power to the machine is cut off, you need to reset the correct time and date once power is restored.

- 1 Press **Menu** until "Machine Setup" appears on the top line of the display.
- 2 Press the scroll button (◀ or ▶) to display "Date & Time" on the bottom line and press **Enter**.
- 3 Enter the correct time and date using the number keypad.



|        |  |
|--------|--|
| Month  | = 01 ~ 12  |
| Day    | = 01 ~ 31  |
| Year   | = requires the four digits                         |
| Hour   | = 01 ~ 12 (12-hour mode)<br>00 ~ 23 (24-hour mode) |
| Minute | = 00 ~ 59  |



**NOTE:** The date format may differ from each country.

You can also use the scroll button (◀ or ▶) to move the cursor under the digit you want to correct and enter a new number.

- 4 To select "Am" or "Pm" for 12-hour format, press the \* or # button.

When the cursor is not under the AM or PM indicator, pressing the \* or # button immediately moves the cursor to the indicator.

You can change the clock mode to 24-hour format (e.g. 01:00 PM as 13:00). For details, see "Changing the Clock Mode" on page 1.8.

- 5 Press **Enter** when the time and date on the display is correct.

When you enter a wrong number, the machine beeps and does not proceed to the next step. If this happens, just reenter the correct number.

## Changing the Clock Mode

You can set your machine to display the current time using either a 12-hour or 24-hour format.

- 1 Press **Menu** until "Machine Setup" appears on the top line of the display.
- 2 Press the scroll button (◀ or ▶) until you see "Clock Mode" on the bottom line and press **Enter**.

The clock mode currently set for the machine displays.

- 3 Press the scroll button (◀ or ▶) to select the other mode and then press **Enter** to save the selection.
- 4 To return to Standby mode, press **Stop/Clear**.

---

## Setting Sounds

You can control the following sounds:

- Ringer: You can adjust the ringer volume.
- Alarm Sound: You can turn the alarm sound on or off. With this option set to "On," an alarm tone sounds when an error occurs or fax communication ends.
- Key Sound: With this option set to "On," a key tone sounds each time any key is pressed.
- Speaker Control: You can turn the speaker on or off. With this option set to "Com," the speaker is on until the remote machine answers.
- Speaker volume: You can adjust the speaker volume.

## Speaker Control, Ringer, Key Sound and Alarm Sound

1

- 1 Press **Menu** until "Sound/Volume" appears on the top line of the display.
- 2 Press the scroll button (◀ or ▶) to scroll through the options. Press **Enter** when you see the desired sound option.
- 3 Press the scroll button (◀ or ▶) to display the desired status or loudness for the option you have selected.

You will see the selection on the bottom line of the display.

For the ringer volume, you can select from Off, Low, Med and High. You will also hear the selected loudness. Setting Off turns the ringer off. The machine will work normally even if the ringer is turned off.

- 4 Press **Enter** to save the selection. The next sound option appears.
- 5 If necessary, repeat steps 2 through 4.
- 6 To return to Standby mode, press **Stop/Clear**.

## Speaker Volume

- 1 Press **On Hook Dial**. You will hear a dial tone.
- 2 Press the scroll button (◀ or ▶) until you hear the desired loudness. The display shows the current volume level.
- 3 Press **On Hook Dial** to save the change and return to Standby mode.

---

## Setting the Dial Mode

You can select the type of the telephone dial system where your machine is connected.



---

**NOTE:** The Dial Mode setting may be unavailable depending on your country.

---

- 1** Press **Menu** until "Machine Setup" appears on the top line of the display.
- 2** Press the scroll button (◀ or ▶) until you see "Dial Mode" on the bottom line and press **Enter**.
- 3** Press the scroll button (◀ or ▶) to select the desired dial mode.  
  
Select "Tone" if your machine is connected to a tone dial line.  
  
Select "Pulse" if the machine is connected to a pulse dial line.
- 4** Press **Enter** to save the selection.
- 5** To return to Standby mode, press **Stop/Clear**.

## Using the Toll Save Mode

Using the **Toll Save** button on the control panel, you can quickly set your machine to send the document(s) stored in the memory during the preset time slot, when the call charge is lowered. This Toll Save mode helps you to take advantage of lower long distance rates at night, for example.



**NOTE:** The toll-saving time slot may vary depending on your contract with a long distance phone company.

To turn the Toll Save mode on:

- 1 Press **Toll Save**. The button backlight turns on.
- 2 Press **Enter** when "Start Time" displays on the bottom line.
- 3 Enter the time when your machine starts sending toll save faxes, using the number keypad.  
  
To select "Am" or "Pm" for 12-hour format, press the \* or # button.
- 4 Press **Enter** when the start time on the display is correct.
- 5 Press the scroll button (◀ or ▶) to display "End Time" and press **Enter**.
- 6 Enter the time when the Toll Save transmission ends, using the number keypad.
- 7 Press **Enter** to save the setting.
- 8 To return to Standby mode, press **Stop/Clear**.

Once the Toll Save mode is activated, your machine stores all of the documents to be faxed into the memory and sends them at the programed time.



**NOTE:** You can change the toll-saving time in the **Advaced Fax** menu. See page 5.5.

To turn the Toll Save mode off, press **Toll Save** again. The button backlight turns off and the mode is deactivated.



---

## Setting up the Fax System

From the **Fax Setup** menu, you can configure various settings for the fax system.

### Changing the Fax Setup options

- 1 Press **Menu** until "Fax System" appears on the top line of the display.  
  
The first available menu item, "Receive Mode," displays on the bottom line.
- 2 Press the scroll button (◀ or ▶) until you see the desired menu item on the bottom line and press **Enter**.
- 3 Use the scroll button (◀ or ▶) to find the desired status or use the number keypad to enter the desired value for the option you have selected.
- 4 Press **Enter** to save the selection. The next Fax Setup option appears.
- 5 If necessary, repeat steps 2 through 4.
- 6 To return to Standby mode, press **Stop/Clear**.

### Available Fax Setup Options

| Option       | Description   |
|--------------|---|
| Receive Mode | <p>You can select the default fax receiving mode.</p> <ul style="list-style-type: none"><li>• In the <b>Fax</b> mode, the machine answers an incoming call and immediately goes into fax reception mode.</li><li>• In the <b>Tel</b> mode, you can receive a fax by pressing <b>Start Copy/Fax</b> on the control panel when you can hear a fax tone on the line.</li></ul> |

| Option         | Description   |
|----------------|---|
| Ring To Answer | You can specify the number of times the machine rings, 1 to 7, before answering an incoming call.   |
| Contrast       | <p>You can select the default contrast mode to fax your documents lighter or darker.</p> <ul style="list-style-type: none"> <li>• <b>Lighten</b> works well with dark print.</li> <li>• <b>Normal</b> works well with standard typed or printed documents.</li> <li>• <b>Darken</b> works well with light print or faint pencil markings.</li> </ul>  |
| Redial Term    | Your machine can automatically redial a remote fax machine if it was busy. Intervals from 1 to 15 minutes can be entered.   |
| Redials        | You can specify the number of redial attempts, 0 to 13. If you enter <b>0</b> , the machine will not redial.  |
| MSG Confirm    | You can set your machine to print a report showing whether the transmission was successful, how many pages were sent, and more. The available options are <b>On</b> , <b>Off</b> and <b>On-Error</b> , which prints only when a transmission is not successful.   |
| Auto Report    | A report with detailed information about the previous 50 communications operations, including time and dates. The available options are <b>On</b> or <b>Off</b> .   |
| Auto Reduction | <p>When receiving a document as long as or longer than the paper loaded in the paper tray, the machine can reduce the size of the document to fit the size of paper loaded in the machine. Select <b>On</b> if you want to automatically reduce an incoming page.</p> <p>With this feature set to <b>Off</b>, the machine cannot reduce the document to fit onto one page, the document is divided and printed in actual size on two or more pages.</p> |

| Option       | Description  |
|--------------|--|
| Discard Size | <p>When receiving a document as long as longer than the paper installed in your machine, you can set the machine to discard any excess at the bottom of the page. If the received page is outside the margin you set, it will print on two sheets of paper at the actual size.</p> <p>If the document is within the margin and the Auto Reduction feature is turned on, it will be reduced to fit into the appropriate sized paper and discard does not occur. If the Auto Reduction feature is turned off or fails, the data within the margin will be discarded. Settings range from 0 to 30 mm.</p> |



# 2

## GENERAL FAX FUNCTIONS

The following topics are included:

- **Sending a Fax**
- **Receiving a Fax**

---

## Sending a Fax

### Preparing Documents for Faxing


Use the following guidelines to prepare your documents for faxing:

- Do not load documents smaller than 142 x 148 mm or larger than 216 x 356 mm in the Automatic Document Feeder (ADF).
- Do not attempt to load the following types of documents into the ADF:
  - carbon-paper or carbon-backed paper
  - coated paper
  - onion skin or thin paper
  - wrinkled or creased paper
  - curled or rolled paper
  - torn paper
- Remove all staples and paper clips before loading documents in the ADF.
- Make sure any glue, ink or correction fluid on the paper is completely dry before loading documents in the ADF.
- Do not load documents containing different sizes or weights of paper in the ADF.
- If you want to make copies from booklets, pamphlets, transparencies or documents having other unusual characteristics, use the document glass to load the document.


### Loading an Original Document

To fax a document using the Automatic Document Feeder (ADF):

- 1 Slide the document **face up** into the ADF. You can insert up to 30 sheets at a time.




- 2 Adjust the document guide on the ADF to match the width of the document.




2

To fax a document from the document glass:

- 1 Open the document cover.



- 2 Place the document **face down** on the document glass and align it with the registration guide on the top left corner of the glass.



### 3 Close the document cover.



#### NOTES:

- If you are copying a page from a book or magazine, lift the cover until its hinges are caught by the stopper and then close the cover. If the book or magazine is thicker than 30 mm, start copying with the cover open.
- Make sure that no document is in the ADF. If any document is detected in the ADF, it has priority over the document on the document glass.

## Adjusting the Document Resolution

The default document settings produce good results when setting typical text based documents.

However, if you send documents that are of a poor quality, or contain photographs, you can adjust the resolution to produce a higher quality fax.

- 1 Press **Resolution**.
- 2 By pressing **Resolution** or the scroll button (◀ or ▶), you can choose from Standard, Fine, Super Fine, Photo and Color.
- 3 When the desired mode is displayed, press **Enter** to save the selection.

The document types recommended for the resolution settings are described in the table below.

| Mode       | Recommended for:  |
|------------|---|
| Standard   | Documents with normal sized characters.   |
| Fine       | Documents containing small characters or thin lines or documents printed using a dot-matrix printer.  |
| Super Fine | Documents containing extremely fine detail. The Super Fine mode is enabled only if the remote machine also supports the Super Fine resolution. See the notes below. |
| Photo      | Documents containing shades of gray or photographs.   |

| Mode  | Recommended for:   |
|-------|--|
| Color | Documents with colors. Sending a color fax is enabled only if the remote machine supports color fax reception and you send the fax manually. In this mode, the memory transmission is not available. |



#### NOTES:

- For the memory transmission, the Super Fine mode is not available. The resolution setting will be automatically changed to Fine.
- If your machine is set to Super Fine resolution and the remote fax machine does not support the Super Fine resolution, the machine will transmit using the highest resolution mode supported by the remote fax machine.

## Sending a Fax Automatically

- 1 Load the document(s) face up into the ADF.

OR

Place a single document face down on the document glass.

For details about loading a document, see page 2.2.

- 2 Adjust the document resolution to suit your fax needs (see page 2.4).

If you need to change the contrast, see page 1.13.

- 3 Enter the remote fax phone number using the number keypad.

You can use one or two-digit speed or group dial numbers. For details, see Chapter 3, "Automatic Dialing."

- 4 Press **Start Copy/Fax**.

- 5 If the document is loaded on the document glass, the display shows "Another Page?" on the top line after the document is scanned into the memory. If you have the next page, remove the scanned page and load the next page on the glass and select "1.Yes." Repeat as necessary.

When all of the pages are scanned, select "2.No" when the display shows "Another Page?."



- 6 The number is dialed and then the machine begins sending the fax when the remote fax machine is ready.



---

**NOTE:** If you want to cancel the fax job, press **Stop/Clear** at any time while sending the fax.

---

## Sending a Fax Manually

- 1 Load the document(s) face up into the ADF.  
  
OR  
  
Place a single document face down on the document glass.  
  
For details about loading a document, see page 2.2.
- 2 Adjust the document resolution to suit your fax needs (see page 2.4).  
  
If you need to change the contrast, see page 1.13.
- 3 Press **On Hook Dial**. You hear a dial tone.
- 4 Enter the remote fax machine's fax number using the number keypad.
- 5 When you hear a high-pitched fax signal from the remote fax machine, press **Start Copy/Fax**.



---

**NOTE:** If you want to cancel the fax job, press **Stop/Clear** at any time while sending the fax.

---

## Confirming Transmission

When the last page of your document has been sent successfully, the machine beeps and returns to Standby mode.

If something goes wrong while sending your fax, an error message appears on the display. **For a listing of error messages and their meanings, see the MFP User's Guide.**

If you receive an error message, press **Stop/Clear** to clear the message and try to send the document again.

You can set your machine to print a confirmation report automatically each time sending a fax is completed. For further details, see the MSG Confirm item in "Available Fax Setup Options" on page 1.12.

## Automatic Redialing

If the number you have dialed is busy or there is no answer when you send a fax, the machine will automatically redial the number every three minutes up to five times by the factory default settings.

When the display shows "Retry Redial ?," press **Enter** to redial the number without waiting. To cancel the automatic redialing, press **Stop/Clear**.

To change the time interval between redials and the number of redial attempts. See page 1.12.

---

## Receiving a Fax

### About Receiving Modes

Your machine provides two receiving modes:

- In Fax mode, the machine answers an incoming fax call and immediately goes into fax reception mode.
- In Tel mode, you can receive a fax pressing **Start Copy/Fax** on the control panel of your machine when you can hear a fax tone from the remote machine.

If the memory is full, the receiving mode automatically switches to Tel.

For details about changing the receiving mode, see page 1.12.



**NOTE:** If you do not want other people to view your received documents, you can use the Secure Fax mode. In this mode, all received faxes are stored in the memory. For further details, see page 5.2.

## Loading Paper for Receiving Faxes

The instructions for loading paper in the paper tray are the same whether you are printing, faxing, or copying, except that faxes can only be printed on Letter-, A4- or Legal-sized paper. For details about loading paper and setting the paper size in the tray, refer to the MFP User's Guide.

## Receiving Automatically in Fax Mode

Your machine is preset to Fax mode at the factory.

When you receive a fax, the machine answers the call on a specified number of rings and automatically receives the fax.

To change the number of rings, see "Advanced Fax Setting Options" on page 5.6.

If you want to adjust the ringer volume, see "Setting Sounds" on page 1.8.

## Receiving Manually in Tel Mode

When a fax comes in, your machine sounds the ringer and then you can hear a fax tone. Press **Start Copy/Fax**.

The machine begins receiving a fax and returns to Standby mode when the reception is completed.

## Receiving Faxes in the Memory

Since your machine is a multi-tasking device, it can receive faxes while you are making copies or printing. If you receive a fax while you are copying or printing, your machine stores incoming faxes in the memory. Then, as soon as you finish copying or printing, the machine automatically prints the faxes.



# 3

## AUTOMATIC DIALING

The following topics are included:

- **Speed Dialing**
- **Group Dialing**
- **Searching for a Number in the Memory**
- **Printing a Phonebook List**

---

## Speed Dialing

You can store up to 60 frequently dialed numbers in one or two-digit speed dial locations (0-59).

### Storing a Number for Speed Dialing

- 1 Press **Phonebook** on the control panel.
- 2 Press **Phonebook** or the scroll button (◀ or ▶) to display "Store/Edit" on the bottom line of the display. Press **Enter**.
- 3 Press **Enter** when "Speed Dials" appears on the display.
- 4 Enter a one or two-digit speed dial number between 0 and 59, using the number keypad and press **Enter**.

If a number is already stored in the location you chose, the display shows the number to allow you to change it. To start over with another speed-dial number, press **Stop/Clear**.

- 5 Enter the number you want to store using the number keypad and press **Enter**.

To insert a pause between numbers, press **Redial/Pause** and a "-" appears on the display.

- 6 To assign a name to the number, enter the desired name. For details on how to enter names, see "Entering Characters Using the Number Keypad" on page 1.5.

OR

If you do not want to assign a name, skip this step.

- 7 Press **Enter** when the name appears correctly or without entering a name.
- 8 To store more fax numbers, repeat steps 4 through 7.

OR

To return to Standby mode, press **Upper Level** or **Stop/Clear**.

## Sending a Fax using a Speed Number

- 1 Feed the document(s) face up into the ADF.

Or

Place a single document face down on the document glass.

For details about loading a document, see page 2.2.

- 2 Adjust the document resolution to suit your fax needs (see page 2.4).

If you need to change the contrast, see page 1.13.

- 3 Enter the speed dial number.

- For a one-digit speed dial number, press and hold down the appropriate digit button.
- For a two-digit speed dial number, press the first digit button and hold down the last digit button.

The corresponding entry's name briefly displays.

- 4 The document scans into the memory.

If the document is loaded on the document glass, the LCD display asks if you want to send another page. Select "1.Yes" to add more documents or "2.No" to begin sending the fax immediately.

- 5 The fax number stored in the speed dial location will be automatically dialed. The document is sent when the remote fax machine answers.

---

## Group Dialing

If you frequently send the same document to several destinations, you can create a group of these destinations and set them under a one or two-digit group dial location. This enables you to use a group dial number setting to send the same document to all the destinations in the group.

### Setting Group Dial

- 1 Press **Phonebook** on the control panel.
- 2 Press **Phonebook** or the scroll button (◀ or ▶) to display "Store/Edit" on the bottom line of the display. Press **Enter**.
- 3 Press the scroll button (◀ or ▶) to display "Group Dials" on the bottom line and press **Enter**.
- 4 Press **Enter** when "New" displays on the bottom line.
- 5 Enter the desired group number between 0 and 59 and press **Enter**.
- 6 Enter a one or two-digit speed number you want to include in the group and press **Enter**.
  - For a one-digit speed dial number, press and hold down the appropriate digit button.
  - For a two-digit speed dial number, press the first digit button and hold down the last digit button.
- 7 Repeat Step 6 to enter other speed dial numbers into the group.
- 8 Press **Upper Level** or the right scroll button (▶) when you entered all of the desired numbers. The display asks you to enter a group ID.
- 9 To assign a name to the group, enter the desired name.  
  
OR  
  
If you do not want to assign a name, skip this step.

**10** Press **Enter** when the name appears correctly or without entering a name.

**11** If you want to assign another group, repeat from Step 4.

OR

To return to Standby mode, press **Stop/Clear**.



**NOTE:** You cannot include one group dial number in another group dial number.

## Editing Group Dial Numbers

You can delete a specific speed dial number from a selected group or add a new number to the selected group.

- 1** Press **Phonebook** on the control panel.
- 2** Press **Phonebook** or the scroll button (◀ or ▶) to display "Store/Edit" on the bottom line of the display.
- 3** Press the scroll button (◀ or ▶) to display "Group Dials" on the bottom line and press **Enter**.
- 4** Press the scroll button (◀ or ▶) to display "Edit" on the bottom line and press **Enter**.
- 5** Enter the group number you want to edit and press **Enter**.

The display prompts you to enter a speed dial number.

- 6** Enter a speed dial number to be added or deleted.
  - For a one-digit speed dial number, press and hold down the appropriate digit button.
  - For a two-digit speed dial group number, press the first digit button and hold down the last digit button.

If you entered the specific number from the group, the display shows "Delete?."

If you entered a new number, the display shows "Add?."

- 7** Press **Enter**.



**8** If you want to edit another group, repeat from Step 4.

Or

To return to Standby mode, press **Stop/Clear**.

## **Sending a Fax Using Group Dialing (Multi-address Transmission)**

You can use group dialing for Broadcasting transmission or Delayed transmission.

Follow the procedure of the desired operation (Broadcasting fax transmission; see page 4.2, Delayed fax transmission; see page 4.3). When you come to a step in which the display asks you to enter the remote fax number:

- For a one-digit group number, press and hold down the appropriate digit button.
- For a two-digit group number, press the first digit button and hold down the last digit button.

You can use only one group number for one operation. Then continue the procedure to complete the desired operation.

Your machine automatically scans the document loaded in the Automatic Document Feeder or on the document glass into the memory. The machine dials each of the numbers included in the group.

---

## Searching for a Number in the Memory

There are two ways to search for a number in the memory. You can either scan from A to Z sequentially, or you can search using the first letter of the name associated with the number.

### Searching Sequentially through the Memory

- 1 Press **Phonebook**.
- 2 Press **Enter** when "Search/Dial" appears on the display.
- 3 Press the scroll button (◀ or ▶) to scroll through the memory until the name and number you want to dial display. You can search upwards or downwards through the entire memory in alphabetical order, from A to Z.

While searching through the machine's memory, you can see that each entry is preceded by one of two letters; "S" for speed dial or "G" for group dial number. These letters tell you how the number is stored.

- 4 When the name and/or the number you want displays, press **Start Copy/Fax** or **Enter** to dial.

### Searching with a Particular First Letter

- 1 Press **Phonebook**.
- 2 Press **Enter** when "Search/Dial" appears on the display.
- 3 Press the button labeled with the letter you want to search for. A name beginning with the letter displays.

For example, if you want to find the name "MOBILE," press the **6** button, which is labeled with "MNO."

- 4 Press the scroll button (◀ or ▶) to display the next name.
- 5 When the name and/or the number you want displays, press **Start Copy/Fax** or **Enter** to dial.

---

## Printing a Phonebook List

You can check your automatic dial setting by printing a Phonebook list.

- 1 Press **Phonebook**.
- 2 Press **Phonebook** or the scroll button (◀ or ▶) until "Print" appears on the bottom line and press **Enter**.

A list showing your speed dial and group dial entries prints out.



# 4

## OTHER WAYS TO FAX

The following topics are included:

- **Redialing**
- **Sending Broadcasting Faxes**
- **Sending a Delayed Fax**
- **Sending a Priority Fax**
- **Adding Documents To a Scheduled Fax**
- **Canceling a Scheduled Fax**

---

## Redialing

To redial the number you last called:

Press **Redial/Pause**.

If a document is loaded in the ADF (Automatic Document Feeder; see page 2.2), the machine automatically begins to send.

For the document loaded on the document glass, the display asks if you want to load another page. Select "1.Yes" to add. Otherwise, select "2.No."

---

## Sending Broadcasting Faxes

Using the **Broadcasting** button on the control panel, you can use the broadcasting fax feature, which allows you to send a document to multiple locations. Documents are automatically stored in the memory and sent to a remote station. After transmission, the documents are automatically erased from the memory.

- 1 Load the document(s) face up into the ADF.

OR

Place a single document face down on the document glass.

For details about loading a document, see page 2.2.

- 2 Adjust the document resolution to suit your fax needs (see page 2.4).

If you need to change the contrast, see page 1.13.

- 3 Press **Broadcasting** on the control panel.

- 4 Enter the number of the remote machine using the number keypad.

You can use one or two-digit speed dial or group dial numbers. For details, see Chapter 3, "Automatic Dialing."

- 5 Press **Enter** to confirm the number. The display asks you to enter another fax number to send the document.



**NOTE:** Your machine can send one broadcasting fax to multiple destinations. The "Enter Number" prompt does not appear if a broadcast is set up and not completed. You must wait until the current broadcast is completed.

- 6 If you want to enter more fax numbers, repeat steps 4 and 5. You can add up to 10 destinations.

Note that you cannot use group dial numbers for another fax number.

- 7 When you finish entering fax numbers, press **Start Copy/Fax**.

The document is scanned into the memory before transmission. The display shows the memory capacity and the number of pages being stored in the memory.

For the document loaded on the document glass, the display asks if you want to load another page. Select "1.Yes" to add. Otherwise, select "2.No."

- 8 The machine begins sending the document in order of the numbers you entered.

## Sending a Delayed Fax

You can set your machine to send a fax at a later time when you will not be present.

- 1 Load the document(s) face up into the ADF.

OR

Place a single document face down on the document glass.

For details about loading a document, see page 2.2.

- 2 Adjust the document resolution to suit your fax needs (see page 2.4).

If you need to change the contrast, see page 1.13.

**3** Press **Menu** until "Fax Feature" appears on the top line of the display. The first available menu item, "Delay Fax" displays on the bottom line.

**4** Press **Enter**.

**5** Enter the number of the remote machine using the number keypad.

To enter the number, you can use one or two-digit speed dial or group dial numbers. For details, see Chapter 3, "Automatic Dialing."

**6** Press **Enter** to confirm the number on the display. The display asks you to enter a name.

**7** If you want to assign a name to the transmission, enter the name. If not, skip this step.

For details on how to enter the name using the number keypad, see "Entering Characters Using the Number Keypad" on page 1.5.

**8** Press **Enter**. The display shows the current time and asks you to enter the start time when the fax is to be sent.



**9** Enter the time using the number keypad.

To select "Am" or "Pm" for 12-hour format, press the \* or # button.

If you set a time earlier than the current time, the document will be sent at that time on the following day.

**10** Press **Enter** when the start time displays correctly.

**11** The document is scanned into the memory before transmission. The display shows the memory capacity and the number of pages being stored in the memory.

For the document loaded on the document glass, the display asks if you want to load another page. Select "1.Yes" to add. Otherwise, select "2.No."

- 12 The machine returns to Standby mode. The display reminds you that you are in Standby mode and that a delayed fax is set.



**NOTE:** If you want to cancel the delayed transmission, see "Canceling a Scheduled Fax" on page 4.8.

---

## Sending a Priority Fax

Using the Priority Fax feature, a high priority document can be sent ahead of reserved operations. The document is scanned into the memory and transmitted when the current operation is finished. In addition, the priority transmission will interrupt a broadcast operation between stations (i.e., when transmission to station A ends, before transmission to station B begins) or between redial attempts.

- 1 Load the document(s) face up into the ADF.  
OR  
Place a single document face down on the document glass.  
For details about loading a document, see page 2.2.
- 2 Adjust the document resolution to suit your fax needs (see page 2.4).  
If you need to change the contrast, see page 1.13.
- 3 Press **Menu** until "Fax Feature" appears on the top line of the display.
- 4 Press the scroll button (◀ or ▶) to display "Priority Fax" on the bottom line and press **Enter**.
- 5 Enter the number of the remote machine using the number keypad.

To enter the number, you can use one or two-digit speed dial or group dial numbers. For details, see Chapter 3, "Automatic Dialing."



- 6 Press **Enter** to confirm the number. The display asks you to enter a name.
- 7 If you want to assign a name to the transmission, enter the name. If not, skip this step.

For details on how to enter a name using the number keypad, see "Entering Characters Using the Number Keypad" on page 1.5.

- 8 Press **Enter**.

The document is scanned into the memory before transmission. The display shows the memory capacity and the number of pages being stored in the memory.

For the document loaded on the document glass, the display asks if you want to load another page. Select "1.Yes" to add. Otherwise, select "2.No."

- 9 The machine shows the number being dialed and begins sending the document.

---

## Adding Documents To a Scheduled Fax

You can add documents to the delayed transmission previously reserved in your machine's memory.

- 1 Load the document(s) face up into the ADF.

OR

Place a single document face down on the document glass.

For details about loading a document, see page 2.2.

- 2 Adjust the document resolution to suit your fax needs (see page 2.4).

If you need to change the contrast, see page 1.13.

- 3 Press **Menu** until "Fax Feature" appears on the top line of the display.

- 4 Press the scroll button (◀ or ▶) to display "Add/Cancel" on the bottom line and press **Enter**.

- 5 Press **Enter** when "Add Page" displays on the bottom line. The display shows the last job reserved in the memory.

- 6 Press the scroll button (◀ or ▶) until you see the fax job to which you want to add documents and press **Enter**.

The machine automatically stores the documents in the memory, and the display shows the memory capacity and the number of pages.

For the document loaded on the document glass, the display asks if you want to load another page. Select "1.Yes" to add. Otherwise, select "2.No."

- 7 After storing, the machine displays the numbers of total pages and added pages and then returns to Standby mode.

---

## Canceling a Scheduled Fax

- 1 Press **Menu** until "Fax Feature" appears on the top line of the display.
- 2 Press the scroll button (◀ or ▶) to display "Add/Cancel" on the bottom line and press **Enter**.
- 3 Press the scroll button (◀ or ▶) to display "Cancel Job" and press **Enter**. The display shows the last job reserved in the memory.
- 4 Press the scroll button (◀ or ▶) until you see the fax job you want to cancel, and press **Enter**.

The selected job is canceled and the machine returns to Standby mode.



# 5

## ADDITIONAL FEATURES

The following topics are included:

- **Using the Secure Fax Mode**
- **Printing Reports**
- **Using Advanced Fax Settings**
- **Using the Remote Control Panel**

---

## Using the Secure Fax Mode

You may need to prevent your received faxes from being accessed by unauthorized people. You can turn on the Secure Fax mode using the Secure Receive option to restrict printing out all of the received faxes when the machine is unattended. In Secure Fax mode, all incoming faxes will go in the memory. When the mode turns off, any faxes stored will be printed.

To turn the Secure Fax mode on:

- 1 Press **Menu** until "Advanced Fax" appears on the top line of the display.
- 2 Press the scroll button (◀ or ▶) until "Secure Receive" appears on the bottom line and press **Enter**.
- 3 Press the scroll button (◀ or ▶) to display "On" on the bottom line and press **Enter**.
- 4 Enter a four-digit passcode you want to use, using the number keypad and press **Enter**.



---

**NOTE:** You can use the Secure Fax mode without setting a passcode, but cannot protect your faxes.

---

Now, the Secure Fax mode is activated and the display shows "Secure Fax RCV."

- 5 To return to Standby mode, press **Stop/Clear**.

When a fax is received in Secure Fax mode, your machine stores it into the memory.

To print received documents:

- 1 Access the **Secure Receive** menu by following Step 1 and 2 above.
- 2 Press the scroll button (◀ or ▶) to display "Print" on the bottom line and press **Enter**.
- 3 Enter the four-digit passcode and press **Enter**.

The received faxes stored in the memory are printed all together.

To turn the Secure Fax mode off:

**1** Access the **Secure Receive** menu by following Step 1 and 2 in "To turn the Secure Fax mode on."

**2** Press the scroll button (◀ or ▶) to display "Off" on the bottom line and press **Enter**.

**3** Enter the four-digit passcode and press **Enter**.

The Secure Fax mode is deactivated and the received faxes stored in the memory are printed all together.

**4** To return to Standby mode, press **Stop/Clear**.

---

## Printing Reports

Your machine can print reports containing useful information. The following reports are available:

### Phonebook List

This list shows all of the numbers currently stored in the machine's memory as speed dial and group dial numbers.

You can print this Phone Book list using the **Phonebook** button; see page 3.8.

### Sent Fax Report

This report shows information of the faxes you recently sent.

### Received Fax Report

This report shows information of the faxes you recently received.

### System Data List

This list shows the status of the user-selectable options. You may print this list to confirm your changes after changing any settings.

## Scheduled Job Information

This list shows the document currently stored for Delayed faxes or Toll Save faxes. The list shows the starting time and type of operation.

## Message Confirmation

This report shows the fax number, the number of pages, the elapsed time of the job, the communication mode, and the communication results.

You can set up your machine to print the message confirmation report automatically after each fax job. See page 1.13.

## Junk Fax Number List

This list shows up to 10 fax numbers specified as the junk fax numbers by using the **Junk Fax Setup** menu; see page 5.6. When the Junk Fax Barrier feature is turned on, incoming faxes from those numbers will be blocked.

## Multi-Communication Report

This report is printed automatically after sending documents from more than one location.

## Power Failure Report

This report is printed out automatically when power is restored after a power failure, if there occurs any data loss due to the power failure.



---

**NOTE:** The list you have set to print out automatically will not print out when there is no paper loaded or a paper jam has occurred.

---

## Printing a Report

- 1 Press **Menu** until "Reports" appears on the top line of the display. The first available menu item, "Phone Book" displays on the bottom line.
- 2 Press the scroll button (◀ or ▶) to display the report or list you want to print on the bottom line.
  - Phone Book: Phonebook list
  - Sent Report: Sent fax report

- **RCV Report:** Received fax report
- **System Data:** System data list
- **Scheduled Jobs:** Scheduled job information
- **MSG Confirm:** Message confirmation
- **Junk Fax List:** Junk fax number list

**3** Press **Enter**.

The selected information prints out.

---

## Using Advanced Fax Settings

Your machine has various user-selectable setting options for sending or receiving faxes. These options are preset at the factory, but you may need to change them. To find out how the options are currently set, print the System Data list. For details about printing the list, see "Printing Reports" on page 5.3.

### Changing Setting Options

- 1** Press **Menu** until "Advanced Fax" appears on the top line of the display. The first available menu item, "**Send Forward**," displays on the bottom line.
- 2** Press the scroll button (◀ or ▶) until you see the desired menu item on the bottom line and press **Enter**.
- 3** When the option you want appears on the display, choose the desired status by pressing the scroll button (◀ or ▶) or enter the desired value using the number keypad.
- 4** Press **Enter** to save the selection.
- 5** You can exit from setup mode at any time by pressing **Stop/Clear**.



## Advanced Fax Setting Options

| Option         | Description  |
|----------------|--|
| Send Forward   | <p>You can set the machine to always forward all of the outgoing faxes to the specified destination besides the fax numbers you entered.</p> <p>Select <b>Off</b> to turn this feature off.<br/>           Select <b>On</b> to turn this feature on. You can set the number of the remote fax machine to which faxes are forwarded.</p>  |
| RCV Forward    | <p>You can set your machine to forward incoming faxes to another fax number during a specified time period. When a fax arrives at your machine, it is stored in the memory. Then, the machine dials the fax number that you have specified and sends the fax.</p> <p>Select <b>Off</b> to turn this feature off.<br/>           Select <b>On</b> to turn this feature on. You can set the fax number to which faxes are forwarded. Then, you can enter the start time and/or the end time. The Print Local Copy option allows you to set the machine to print the fax, if fax forwarding is completed with no error.</p> |
| Toll Save      | <p>You can set the start time and/or the end time for toll save mode. For details about sending toll save faxes, see page 1.11.</p>  |
| Junk Fax Setup | <p>Using the Junk Fax Barrier feature, the system will not accept faxes sent from remote stations of which their numbers are stored in the memory as junk fax numbers. This feature is useful for blocking any unwanted fax.</p> <p>Select <b>Off</b> to turn the feature off. Anybody can send you a fax.<br/>           Select <b>On</b> to turn the feature on. You can set up to 10 fax numbers as junk fax numbers. After storing numbers, you do not receive any faxes from the registered stations.</p>   |
| Secure Receive | <p>You can keep your received faxes from being accessed by unauthorized people.</p> <p>For further details about setting this mode, see page 5.2.</p>  |
| Prefix Dial    | <p>You can set a prefix dial number of up to five digits. This number dials before any auto dial number is started. It is useful for accessing the PABX exchange.</p>  |

| Option         | Description  |
|----------------|--|
| Stamp RCV Name | <p>This option allows the machine to automatically print the page number, and the date and time of the reception at the bottom of each page of a received document.</p> <p>Select <b>Off</b> to turn this feature off.<br/>Select <b>On</b> to turn this feature on.</p>   |
| ECM Mode       | <p>The Error Correction Mode helps with poor line quality and makes sure any fax you send are sent smoothly to any other ECM-equipped fax machine. If the line quality is poor, it takes more time to send a fax when you are using the ECM mode.</p> <p>Select <b>Off</b> to turn this feature off.<br/>Select <b>On</b> to turn this feature on.</p> |

## Using the Remote Control Panel

Using the Remote Control Panel, you can set up fax system data options, create and edit Phonebook entries or view information of your machine on the desktop window of your computer.


When you install the Samsung software, the Remote Control Panel program is automatically installed.

For information about installing the Samsung software, please refer to the MFP User's Guide.

To open the Remote Control Panel:

- 1 Start your Windows.
- 2 Click the **Start** button on your desktop computer.

- 3 From **Programs**, select **Samsung SCX-4x16 Series** and then **Remote Control Panel**.



Then the Remote Control Panel program opens.


- 4 The SCX-4x16 Series Remote Control Panel window provides five tabs; **Settings**, **Advanced**, **Phonebook**, **Information**, and **Firmware Update**.

To exit, click the **Exit** button at the bottom of each tab.

For further details, click the **Help** button at the bottom of each tab.

## The Settings Tab

Click the **Settings** tab to configure fax system settings.



## The Advanced Tab

Click the **Advanced** tab to configure advanced fax system settings.

The screenshot shows the 'Advanced' tab of the Samsung SCX-4x16 Series Remote Control Panel. The interface includes fields for Machine number (0312001114), Machine ID (HELP-DESK), Prefix dial, Speaker (ON), and Ringer (LOW). It also has settings for USB mode (FAST), Language (English), Clock mode (12 hour), and Power save (Off, 30 minutes). There are checkboxes for Alarm sound, Key sound, Stamp receiver name, and ECM mode (checked). A Toll saver section has radio buttons for Off and On, with start and end times. At the bottom, there are buttons for Refresh, Apply, Exit, and Help.

Reads the current settings in your machine and refreshes the Remote Control Panel with them.

Downloads the settings made in Remote Control Panel to your machine.

## The Phonebook Tab

Click the **Phonebook** tab to create and edit Phonebook entries.

The screenshot shows the 'Phonebook' tab of the Samsung SCX-4x16 Series Remote Control Panel. It features a 'Type' section with radio buttons for 'One Touch Dial (1 ~ 10)' and 'Speed Dial (1 ~ 50)'. There are 'Read' and 'Write' buttons. A table lists phonebook entries with columns for No., Name, and Phone Number. The first entry is '1 HARRY PORTER 0011212121212'. Below the table are buttons for 'Edit', 'Delete', 'Delete All', and 'Group dial...'. At the bottom are 'Exit' and 'Help' buttons.

Reads the Phonebook entries from the machine to the Remote Control Panel.

Downloads the Phonebook entries from the Remote Control Panel to the machine.

Phonebook entries


Allows you to edit a selected Phonebook entry in a separate Edit window.

Deletes a selected Phonebook entry.

Deletes all Phonebook entries.

## The Information Tab


Click the **Information** tab to view the software version information and many counters which allow you to check how many scanning, printing, and jamming are made in your machine.



Reads the current information in your machine and refreshes the Remote Control Panel.

## The Firmware Update Tab

Click the **Firmware Update** tab to update the firmware of your machine. This feature should be used by an authorized technician. Please consult with the purchase point.



# INDEX

## A

- add documents 4.7
- ADF, load 2.2
- automatic dialing
  - group 3.4
  - speed 3.2
- automatic redialing 2.7

## B

- broadcasting faxes 4.2

## C

- canceling
  - fax 2.6
  - scheduled faxes 4.8
- characters, enter 1.5
- clock mode, change 1.8
- contrast, set 1.13
- control panel 1.2

## D

- date and time, set 1.7
- delayed fax 4.3
- dial mode, set 1.10
- document
  - load
    - ADF 2.2
    - document glass 2.3
  - prepare 2.2
- document glass, load 2.3

## F

- fax system, set
  - advanced settings 5.5
  - options 1.12

## G

- group dial
  - dialing 3.6
  - editing 3.5
  - setting 3.4

## M

- machine ID, set 1.4

## P

- paper, load 2.8
- print
  - Phonebook list 3.8
  - reports 5.3
- priority fax 4.5

## R

- receive a fax
  - in FAX mode 2.8
  - in TEL mode 2.8
  - in the memory 2.8
- receive mode, set 1.12
- redial, last number 4.2
- Remote Control Panel 5.7
- reports, print 5.3
- resolution, set 2.4

## S

- search, a number 3.7
- secure fax mode, use 5.2
- send a fax
  - automatically 2.5
  - manually 2.6
- sounds, set 1.8
- speed dial
  - dialing 3.3
  - storing 3.2

## T

toll save mode 1.11

## V

volume, adjust  
ringer 1.9  
speaker 1.9





The Samsung logo is located in the top left corner, consisting of the word "SAMSUNG" in a bold, sans-serif font, enclosed within a white oval shape.

User's Guide

# ***Digital Laser Facsimile***

## ***SCX-4216F***

**For UK customers:**

**To reorder your consumables**  
Call 0800 3164060

**For Technical Assistance**  
Call 0870 2420303